

# Heavy Duty Chiller with Built-In Water Tank



# Energy savings and high precision control

# **ORION Reliability & One Stop Service**

With ORION's One Stop Service, we aim to be your best partner with our motto of providing consistent service throughout, from initially hearing about particular details, to providing periodic maintenance.

\*Specific service offerings may differ depending on the country, region, or model.

Energy Saving **Proposal** 

**Best Match Proposal** 

**Lending Service** 

Post-Delivery Initial **Test Run Confirmation** 

One Month **Inspection Visit**  Paid Fixed-Term Inspections & Maintenance

We have the equipment that meets your needs! See page 11 for details.

We offer free loans of demo machinery Feel free to contact us with any inquiries.

Energy Saving Proposal Example: Change-up from RKL-3750V-C1 to RKE3750B-V

**Energy Savings** Reduction in CO<sub>2</sub> Output Effective Savings

4,818 kg-CO<sub>2</sub>/year 176,250 yen/year

Energy Saving **Points** 

### **Control that Adapts to Fluctuations in Cooling Load**

### Comparison Conditions

Compared Models:


RKL-3750V-C1 (HB Control \*1) RKE3750B-V (Inverter Chiller)

Power souce: Three-phase 200 V 60 Hz

Water Temp Setting: 20 °C Ambient Temperature: 32 °C


6.1 kw (50% of Rated Load) Average Load: Operating Time: 10 hours/day (250 days/year)

Electricity Cost: 15 yen/kWh  Power Consumption Rate According to **Chiller Load Factor** 



\*The rate of power consumption is a value based on 100% being the RKL-3750V-C1 operating at its rated power consumption (7.6 kW), at 60 Hz, under the rated operating conditions.

### • Reduction in CO<sub>2</sub> Output




**Difference in Power Consumption:** 

17,750 kWh - 6,000 kWh = 11,750 kWh **Effective Cost Reduction Due to Energy Savings:** 

11,750 kWh/year × 15 yen/kWh = 176,250 yen/year

### Yearly Power Consumption Comparison



- \*1 HB Control = Hot Gas Bypass Control. Liquid temperature is controlled by bypassing high-temperature refrigerant gas to the evaporator.
- \*2 The CO<sub>2</sub> emission coefficient used is 0.410, which is the average of 8 power companies.

# **Global Service Network**

**Europe Service Network** 

**North America Service Network** 

**East Asia Service Network** 



**ASEAN & South Asia Service Network** 

Our service network is developing in Asia, Europe, North America and South America. We make effort to expand the network into the future.

### **East Asia Service Network**

ORION Machinery (Shanghai) Co., Ltd. (China) Dongguan Orion Machinery Co., Ltd. (China) ORION (HONG KONG) Co., Ltd. (Hong Kong) ORION KOREA Co., Ltd. (South Korea) Taiwan Orion Industry Co., Ltd. (Taiwan)

### **ASEAN Service Training Center**

ORION Machinery Asia Co., Ltd. (Thailand)

### Europe Service Network

Europe Customer Support Center Limko N.V. (Belgium)

Italy U.K. Germany France Sweden Norway Hungary Czech

### **ASEAN & South Asia Service Network**

Siam Seimitsu (Thailand)
iwatech Malaysia (Malaysia)
iwatech Singapore (Singapore)
VE & JA (Vietnam)
Tan Dai Phu Sy (Vietnam)
MESCO (Philippines)
PT. S-Tech (Indonesia)
GEM Orion Machinery (P) Ltd. (India)

### North America Service Network

North America Customer Support Center ORION Machinery North America (US) Over 150 locations throughout US, Canada and Mexico.

### **South America Service Network**

A&M Engenharia (Brazil)



■ RKE-A Series (Heavy Duty Models) ······ P23 – 24





### CONTENTS

ORION Reliability & One Stop Service P1	■ RKE-A Series (Heavy Duty Water-Cooled Models) ···· P25 – 26
Global Service Network P2	● RKED Series (Digital Control Models) ······ P27 – 28
<b>P3</b> – 10	• Optional Equipment P29 – 31
● Functions ····· P11	<ul> <li>Important Unloading and Placement Information</li> </ul>
Options P12	● RKE-B Series P32 – 36
● Chart of Included Functions ····· P13 – 20	● RKE-A / RKED Series P37 – 41
RKE-B Series (CE Marking) P21 – 22	● Working Principles and Model Configurations ······ P42

# **RKE-B** Series









Energy Saving Points

### **TESC (Triple Eco Speed Control) Built-In**





\*The rate of power consumption is a value based on 100% being the RKL-3750V-C1 operating at its rated power consumption (7.6 kW), at 60 Hz, under the rated operating conditions.


Operates at the minimum speed needed to achieve the required flow rate. Reduces water supply waste.

Our units can maintain control at low loads that were previously difficult to work with and as the graph shows, even compared with previous inverter driven chillers, we've achieved energy savings!

### **Pump Is Also Inverter Driven**

### ■ Inverter Drive for the Compressor, Fan, and Now Also the Pump!

Being able to achieve just the required flow rate eliminates waste, even without bypass-valve control.



### ■ Choose the Desired Pump Control Method

In addition to the operating frequency, the flow rate (\*) or water pressure can be set. Operation is possible at the optimum flow rate or pressure in accordance with the load.









<sup>\*</sup>The noted flow rate is a calculated value. The actual flow rate may differ. If an exact measured flow rate is required, then an external (user supplied) flow gauge should be installed.

### Wide Operable Ambient Temperature Range

Can withstand summer temperatures up to 50 °C with our special-spec. Our chillers can also exhibit maximum performance in factory environments where hot air flow tends to accumulate. In winter temperatures as low as -20 °C, you can count on our air cooled models continuing to perform, even in outside installations.





\* When setting antifreeze operating mode.

### **Wide Operable Liquid Temperature Range**


Operable Liquid Temperature Range: 3 °C to 35 °C Low liquid Temperature Expanded to 3 °C



### Low Noise and Noise Reducing Design

40 dB

Ideal inverter fan speed control through optimized refrigeration cycle control. Achieves much lower operating noise levels.



# **Specifications**

# RKE-B Series Alf-Cooled Models

Specifications
----------------

	Model			RKE3750B-V G1 / G2	RKE5500B-V	RKE7500B-V				
	Cooling Capacity *1		kW	12.2	20.3	25.0				
nce	⊕ Heating Capacity *8 kW			2.8	2.8 3.7					
nar	ि प्रहार   Operable Ambient Temperature Range									
rfor Scifi	Operable Liquid Temperature Range		°C		3 to 35 (w/ brine: 0 to 35) *7					
Heating Capacity *8 Operable Ambient Temperature Range Operable Liquid Temperature Range Control Precision *4				±	).1 °C (Energy saving mode: ±2.0 °C					
	Operating Flow Rate		L / min	15 to 60	60 to	170				
· v	Power Source *2		V (Hz)	Т	hree-phase 200 to 220 ±10% (50/60	))				
tions	Power Consumption *1		kW	5.4	9.8	10.2				
Power Specifications	Electric Current *1		Α	16.5	30.1	33.5				
L 96	Power Capacity *3	kVA		7.0	11.0	11.8				
Breaker Capacity *6 A		Α	30	5	0					
Operation Control Method					Compressor speed control					
	Construction			Fi	Ily sealed rotary type (inverter drive	n)				
	Compressor	Output	kW	1.7	3.0 4.6					
<u>0</u>	Condenser				Fin and tube forced air cooling					
etai	Heat Exchanger	Construct	tion		Plate type heat exchanger					
<del>ا</del> ۲	neat Exchanger	Materia	al		SUS316 (Brazing: Cu)					
quipment Details	Discharge Pump	Construct	tion		/lultistage centrifugal immersion type					
gink	Discharge Fullip	Output	kW	1.1 (Inverter driven)	1.5 (Inverter driven)					
Ш	Fan Motor	Output	kW	0.4 (Inverter driven)	0.75 (Inve	ter driven)				
	Water Tank Capacity		L	Approx. 60	Appro	ox. 90				
	Refrigerant				R-410A					
Exter	nal Dimensions (H×D×W)		mm	G1 : 1410 (G2 : 1536) × 752 × 720	1700 × 8	54 × 870				
Unit N	Mass (dry weight)		kg	G1: 200 / G2: 205	280	290				
Opera	ating Noise Level (50/60 H	lz) *5	dB	60	6	3				


Model				RKE11000B1-V	RKE15000B-V	RKE22000B-V	RKE30000B-V				
	Cooling Capacity *1		kW	37.2	48.0	74.4	96.0				
Performance Specifications	Heating Capacity *8		kW	8.0	10.0	16.0	20.0				
mar	Operable Ambient Temp	erature Range	°C	-20 to 45 (w/ or	otion: -20 to 50)	-20 1	to 45				
rf Scifi	Operable Liquid Tempera	ature Range	°C		3 to 35 (w/ brin	ne: 0 to 35) *7					
ထို Control Precision *4					±0.1 °C (Energy sa	ving mode: ±2.0 °C)					
	Operating Flow Rate		L / min	100 t	o 230	200 t	o 460				
(0	Power Source *2		V (Hz)		Three-phase 200 to	220 ±10% (50/60)					
Power Specifications	Power Consumption *1		kW	13.5	18.1	23.9	37.2				
owe	Electric Current *1		Α	41.4	56.3	73.6	114.9				
be P	Power Capacity *3		kVA	17.7	22.0	34.1	43.3				
0	Breaker Capacity *6		Α	75	100	125	175				
Operation Control Method				Compressor speed control							
	Compressor	Construction		Fully sealed scroll to	d scroll type						
	Compressor	Output	kW	7.46	11.19	7.46 × 2 (Inverter driven)	11.19 × 2 (Inverter driven)				
<u> </u>	Condenser			Fin and tube forced air cooling							
etai	Lleat Evelopeer	Construc	tion	Plate type heat exchanger							
<del>ا</del> ک	Heat Exchanger	Materia	al	SUS316 (Brazing: Cu)							
Equipment Details	Discharge Pump	Construc	tion		Multistage centrifu	gal immersion type					
l ig	Discharge Fullip	Output	kW	4.0 (Inver	ter driven)	4.0 × 2 (Inv	erter driven)				
Ш	Fan Motor	Output	kW	0.4 × 2 (Inv	erter driven)	0.86 × 2 (Inv	verter driven)				
	Water Tank Capacity		L	Appro	x. 100	Appro	x. 250				
	Refrigerant				R-4	10A					
Exter	nal Dimensions (H×D×W)		mm	1700 × 854 × 1380	1800 × 854 × 1610	2190 × 13	40 × 2150				
Unit N	Mass (dry weight)		kg	415	460	1050	1065				
Opera	ating Noise Level (50/60 H	Hz) *5	dB	69	68	63	64				


<sup>\*1.</sup> Operating conditions: Chilled water temp: 20 °C, Ambient temp: 32 °C. Cooling capacity is at least 95% of listed figures. \*2. Source voltage phase unbalance should be less than ±3%. 
\*3. The figure noted is when operating at the highest capacity in the normal operating range. \*4. Continuous current load fluctuation within ±10%, and with stable ambient temp and power supply, etc. Does not include starting times or when the cooling load is too small, in which case the compressor may cycle on and off. \*5. Operating noise levels are from a position of 1 m in front of the unit and at a height of 1 m. \*6. Unit comes with a built-in multi-purpose overload and short circuit protection breaker. \*7. For liquid temperature settings of 0 to 3 °C, use a 30 to 40% solution of industrial-use ethylene glycol. \*8. At time of startup only. Will differ depending on ambient temperature.


Note 1: The recommended liquid (chilled water) that can be used is either clean water or a 30 to 40% ethylene glycol solution. Note that there will be a 10% reduction in cooling capacity if using a 30 to 40% ethylene glycol solution. Alternatively, if deionized water is to be used, it should have an electrical conductivity of at least 1 µS/cm.

Note 2: Heat output from the unit (in kW) is approx. 1.3 times that of the cooling capacity.


### Cooling Capacity Diagram
























### Chilled Water Flow Chart


- \* The illustration shows the actual measured flow rate value when the bypass valve is closed.
- \* Flow rate changes based on inverter frequency
- \* The shaded area indicates the range possible for the adjusted frequency value.
- \* If additives are used, the flow rate characteristics will change due to factors such as the additive used, the concentration, fluid temp, etc.

















# **Specifications**

# RKE-B Series Alf-Cooled Models

### External Dimensions (Units: mm)










Detail of Chilled Water Circuit Parts (RKE3750B-V)

Water Circuit Section Detail (RKE5500/7500B-V)



17.5






### External Dimension Table (units: mm)

· · · · · · · · · · · · · · · · · · ·		,											
Model	W	Н	Α	В	С	D	E	F	G	J	K	L	M
RKE3750B-V	720	1410	826	830	708	752	791	330	197	-	115	126	1536
RKE5500B-V	870	1700	975	990	812	854	940	480		221	110		
RKE7500B-V	870	1700	975	990	012	004	940	400	_	221	110	-	_
RKE11000B1-V	1380	1700	1485	1500	812	854	1450	480	123	223	110	-	-
RKE15000B-V	1610	1800	1715	1730	812	854	1680	480	124	224	110	-	-

# RKE22000B-V RKE30000B-V Water Circuit Section Detail (Tolerance: 15)



- 1. Route signal and communications wiring through access holes separate from power cables.
- 2. General Tolerance JIS B0405(1991)-v


# Specifications RKE-B Series Water-Cooled Models


### Specifications


Model				RKE3750B-VW G1/G2 (w/ casters)	RKE5500B-VW	RKE7500B-VW	RKE11000B1-VW	RKE15000B-VW					
	Cooling Capacity *1		kW	14.1	23.4	27.3	43.0	48.0					
Se	Heating Capacity *8		kW	2.8	3.0	3.1	9.1	10.0					
Performance Specifications	Operable Ambient Temp	erature Range	°C		2 to 45 (w/ or	otion: 2 to 50)		2 to 45					
16,3	Cooling Water Temperat	ture Range	°C		5 to 45								
l Si is	Operable Liquid Temper	ature Range	°C		3 to	35 (w/ option: 0 to 35	5) *7						
P. Sp	Control Precision *4				±0.1 °C (	Energy saving mode:	±2.0 °C)						
	Operating Flow Rate		L/min	15 to 60	60 to	170	100 to	230					
Power secifications	Power Source *2		V (Hz)		Three-phase 20	00 ±10% (50) / 200 to	220 ±10% (60)						
is is	Power Consumption *1		kW	5.1	8.8	10.1	11.7	15.3					
lica fice	Electric Current *1			urrent *1		19.2	31.8	33.0	36.3	48.2			
eci p	Power Capacity *3	*3		8.0	12.2	12.6	17.2	19.5					
ß	ගි Breaker Capacity *6			30 50 75									
Opera	ation Control Method				Co	ompressor speed cont	rol						
	Compressor	Construction		Fully seal	led rotary type (inverte	Fully sealed scroll ty	/pe (inverter driven)						
<u>s</u>	Compressor	Output	kW	1.7	3.0	4.6	7.46	11.19					
Equipment details	Condenser			Double pipe water cooling									
t de	Heat Exchanger	Construction			Pl	ate type heat exchang	jer						
eu	lieat Exchanger	Material			SUS316 (Brazing: Cu)								
1 6	Discharge Pump	Construction			Multista	ge centrifugal immers	ion type						
l ib	Discharge Fullip	Output	kW	1.1 (Inverter driven)	1.5 (Inver	ter driven)	4.0 (Inver	ter driven)					
Ш	Water Tank Capacity		L	Approx. 60	Appro	ox. 90	Appro	x. 100					
	Refrigerant					R-410A							
Exter	nal Dimensions (H×D×W	)	mm	G1: 1410 (G2: 1536) × 752 × 720	1700 × 8	54 × 870	1410 × 85	54 × 1380					
Unit N	lass (dry weight)		kg	G1:200/G2:205	280	290	40	)5					
Opera	ating Noise Level (50/60 I	Hz) *5	dB	58	5	9	61	59					


<sup>\*1.</sup> Operating conditions: Chilled water temp.: 20 °C, Cooling water temp.: 32 °C, Ambient temp.: 32 °C. Cooling capacity is at least 95% of listed figures. \*2. Source voltage phase unbalance should be less than ±3%. \*3. The figure noted is when operating at the highest capacity in the normal operating range. \*4. Continuous current load fluctuation within ±10%, and with stable ambient temp, and power supply, etc. Does not include starting times or when the cooling load is too small, in which case the compressor may cycle on and off. \*5. Operating noise levels are from a position of 1 m in front of the unit and at a height of 1 m. \*6. Unit comes with a built-in multi-purpose overload and short circuit protection breaker. \*7. For liquid temperature settings of 0 to 3 °C, use a 30 to 40% solution of industrial-use ethylene glycol. \*8. At time of startup only. Will differ depending on ambient temperature and cooling water temperature Note 1: The recommended liquid (chilled water) that can be used is either clean water or a 30 to 40% ethylene glycol solution. Note that there will be a 10% reduction in cooling capacity if using a 30 to 40% ethylene glycol solution. Alternatively, if deionized water is to be used, it should have an electrical conductivity of at least 1 µS/cm.


### Cooling Capacity Diagram: Air Cooled Model Cooling Power Comparison Diagram












Cooling water temperature at intake : 5 °C Cooling water temperature at intake : 32 °C Cooling water temperature at intake: 45 °C


### Cooling Water Flow Rate (For the water cooled condenser)





- Actual cooling water flow rate will depend on the water temperature.
- \* Ensure the required quantity of water as shown in the graphs below.


### Chilled Water Flow Chart


- \* The illustration shows the actual measured flow rate value when the bypass valve is closed.
- \* Flow rate changes based on inverter frequency
- \* The shaded area indicates the range possible for the adjusted frequency value.
- \* If additives are used, the flow rate characteristics will change due to factors such as the additive used, the concentration, fluid temp, etc.















### External Dimensions (Units: mm)


RKE3750B-VW RKE5500B-VW RKE7500B-VW












Model	W	Н	Α	В	С	D	E	F	G	J	K	L	M	N
RKE3750B-VW	720	1410	826	830	708	752	791	330	197	-	115	126	1536	869
RKE5500B-VW	870	1700	975	990	812	854	940	480	_	221	110	_	_	939
RKE7500B-VW	070	1700	913	990	012	004	940	400	_	221	110	_	_	939
RKE11000B1-VW	1380	1410	1485	1500	812	854	1450	480	123	223	110	-	-	*
RKE15000B-VW	1380	1410	1485	1500	812	854	1450	480	123	223	110	-	-	-

# RKE-B Series Standard-Equipped Functionality

ORION produces a variety of products geared toward making our Inverter Chillers meet the wide-ranging needs of all of our customers.

### **Intelligent Touch Panel**

Various settings and operating conditions can be visually and intuitively checked and operated via the touch panel controller. The displayed language can be changed to English, Japanese or Chinese.



### 1 Graph Display



Touching the "Measured Liquid Temp." button will change the display to the Graph Screen where changes in liquid temperature will be graphed over a particular time period (up to 53 hours) in order to better aid in liquid temperature management.

### 2 Unit Operating Ratio (Power indicator)



The compressor operating state is indicated on a 10 level bar graph which shows the level of energy saving at a glance.

Touching the "Op. rate" button brings up the Monitor Screen where operating conditions can be easily checked.

### **3 Measured Pressure**

Touch "Measured Pressure" to change the discharge pump control option between frequency, flow rate, and pressure.

### 4 Menu

Touching "Menu" will bring up a menu of useful functions for easy confirmation and setting of Parameters, Alarm History, Main Components, Accumulated Time, Timer Function, etc.

### **© Easy Maintenance/Alarm Display**

set. Actions can be repeated or set according to the day.

Touching "0:00" on the display allows stop and start times to be

Alarm numbers are displayed when alarm conditions occur.

Touching the "Details" (or "Alam!" on 22000 and 3000 models) will show details about the alarm and suggestions on how to deal with it.



**(5) Timer Setting** 



### Displayed language can be changed to English, Japanese or Chinese.



sh language mode


Japanese language mode



20.0° 20.0°

### **Liquid temp Upper / Lower Limit Warning**

A warning message can be displayed or an audible alarm sounded when the liquid temperature goes beyond a set upper or lower limit beyond the set temperature.



### Earth Leakage Breaker (ELB)


To help insure safety, as a preventive measure, the unit includes an earth leakage breaker as standard equipment.





# Supports Linking of Multiple Units As many as 4 units can be connected

RKE22000 and 30000B-V models only.



### Linked Model Example (Number of units)

HP	Cooling capacity (kW)	RKE22000B-V (30HP)	RKE30000B-V (40HP)
30	74	1	-
40	96	-	1
60	148	2	-
80	192	_	2
90	222	3	-
120	288	_	3
160	384	-	4

## RKE-B Series Optional Equipment

We have a wide-ranging lineup of optional equipment to meet every need.

### On-Site Installed Optional Items See pages 13 to 20 for details.

### Water Filter Equipment

Use to prevent clogging in the water circuits of your chiller or other equipment and can also be used as a prefilter for water purification equipment.

•For Circulating Water Systems

When installed as a bypass circuit within the chilled water circulation circuit, it can prevent rises in electrical conductivity in the circulating water.

For Water Supply and Purification

Can suppress sharp rises in electrical conductivity of circulating water that occurs when supplying water to the water tank.



### **Remote Control (Wired)**

Remote Control Sets include cables. The set model number differs depending on the cable length. (Max cable lengths: 20 m, 50 m, 100 m.)



### **Snow Protection Hood**

Ion Exchange Resin Purifying Equipment

The Snow Protection Hood supports outside installations in snowy regions.

### Wind Shield


The Ventilation Hood supports outside installations. The hood also helps to keep dust and dirt out of the unit.



### **Factory Installed Options**


### Heater

At time when the liquid temperature is rising, the heater should be used if high-precision control is required even when the load is low (and there is not the minimum amount of heat required for inverter control).



### **Discharge Pump for High Head Applications**

High flow rate pump built-in. A built-in pump supporting a higher head specification is available.





### Cleanroom (Leakage Alarm Spec.)

Leakage Alarm Spec. models are available for use in cleanrooms.



### Leakage Detection Spec.

If for some reason a water leak occurs, an alarm will be activated.



\* See pages 13, 14, 17 and 18 for details.

### **External Surface Paint Thickness**

The thickness of the applied outer surface paint can be changed to suit particular applications or needs.



### **Meets the Demands of World Markets**

### **CE Marking**

See pages 21 and 22 for details.

### **Other International Standards**

Please consult our sales staff regarding any of your particular needs.

# RKE-B Air-Coolde Series Equipment (Standard / Optional) List

		Function  Item Detail								
	30 to 40% ethylene glycol solution									
	Deionized water. Electrical Cond									
		3 to 35 °C								
	Working Liquid (chilled water) Temperature	0 to 35 °C								
	·									
	Operable Ambient Temp Range	Low temp area spec.: -20 to 45 °C (air cooled), 2 to 45 °C (water cooled)  High temp area spec.: to 50 °C Requires Distribution Panel High-Temperature Set								
		This function operates the discharge pump in order to prevent water temperature drops and freezing								
ent	Freeze-Prevention Mode	during winter months when unit operations is stopped.  When enabled, the discharge pump will operate when the water temperature falls to 3 °C or below.								
g Environment	Warm Up Mode	This function will automatically operate the discharge pump when the unit is otherwise not operating when the imbient temperature is low, for example during winter months, in order to prevent the water temperature from tropping too much and in order to help maintain the set water temperature. When this mode is enabled, the water emperature can be set within the temperature range of 10 °C to 35 °C as desired.								
Operating	Low Noise Mode *2	This function will limit the upper speed of the fan and the fan ventilation noise level will be decreased.								
d	Outside Installation	IPX4 Equiv. Rating								
	Snow Protection Mode	When enabled, and when the unit is stopped, the fan will periodically and automatically start in order to blow fallen snow from the upper exhaust port.								
	Snow Protection Hood	Prevents falling snow from entering the fan intake.								
	Wind Shield	Consider a wind speed of 8 m/s or higher as a guideline.								
	Cleanroom (Leakage Alarm Spec.)	In addition to the standard specification, leakage sensors, pressure resistant piping, refrigerant piping insulation, and water piping insulation are added.								
	Water Leakage Detection	Leak detector built-in.								
	Vibration Reducing Base	Reduces transmission of vibration from the chiller.								
	Discharge Pump Specs.	High flow rate pump built-in. Can replace the built-in high pressure pump.								
	Relief Valve (Pressure valve) Can provide equipment-side pressure protection.									
	Water Tank Water-Level Alarm (Lower limit alarm)	Used to avoid water shortages due to evaporation.								
	Water Supply Port Open/Close	A ball tap is provided in the water tank in order to maintain a uniform water level.								
Circuit		A ball valve is added to the water supply port.								
Ç	Chilled Water Inlet/Outlet Open/	Gate valves are added to the chilled water inlet and outlet ports.								
Water	Close	Compression fittings are added to the chilled water inlet and outlet ports.								
ed V	Chilled Water Circuit Water	Water Filter "A" Assembly								
Chille	Filter	Water Filter "B" Assembly								
O		Water Filter "C" Assembly								
	Deionized Water Equipment for	Water Purifier "C" Assembly								
	Chilled Water Circulation Circuit	Water Purifier "D" Assembly								
	Dejanized Water Facility and for Chilled	Water Purifier "E" Assembly								
	Deionized Water Equipment for Chilled Water Supply and Supply Circuits	Purification assembly for supply water.								
SOS	Primary Power Supply Voltage	4 voltages : Three-phase 200 to 220 V (50/60 Hz)								
Specs	, , , , , ,	Three-phase 230 V (50 Hz), 380 V / 400 V / 415 V / 440 V / 480 V (50/60 Hz)								
Control	Overload Safety Devices	The unit comes with a built in multipurpose overload and short circuit protection breaker.								
S	Power Outage Recovery Operation Settings	Can choose the recovery pattern after power outage. (Manual recovery / Automatic recovery / Remote operation priority)								
y and	Operation Action Settings	Can enable or disable operation from among the main unit, remote control, external communications, or remote switch.								
Supply	Alarm Signal Output Options	Can choose the state of contacts of the remote alarm signal output. (Contacts either ON or OFF during alarm condition.)								
Power St	Action on Compressor Related Alarm	In cases where an alarm signal has been generated, this setting allows the user to choose whether the unit will completely shut down or if components that are able to operate will continue to do so.								
Po	Audible Alarm Enable/Disable	Audible alarm can be enabled or disabled for each audible alarm or warning.								

<sup>\*1.</sup> Note that there will be a 10% reduction in cooling capacity. \*2. Note that there will be max. 20% reduction in cooling capacity. \*3. Copper alloy is used for wetted parts on standard units.

-		Model Ai	ir-Cooled (RK	E Series)	
Comments	3750B-V	5500B-V 7500B-V	11000B1-V	15000B-V	22000B-V 30000B-V
Cannot be mixed with deionized water.		Ор	eration Possi	ble	
Wetted parts are copper-free. *3			<b>*</b>		
			Standard		
Please operate with a 30% to 40% solution of industrial-use ethylene glycol.			Standard		
Be careful of freezing at low temperatures as well as abnormal temperature rises due to placement			Standard		
in direct sunlight.	04105977010	04106046010	-	04107416010	_
Can be enabled or disabled via the intelligent touch panel. * Cannot be used at the same time as the warming up mode.		Sta	ndard Equipm	nent	
Can be enabled or disabled via the intelligent touch panel.  * Cannot be used at the same time as the freeze-prevention mode.		Sta	ndard Equipm	nent	
Can change between normal or low operation modes via the intelligent touch panel.		Sta	ndard Equipm	nent	
Installation in direct sunlight, strong wind (8 m/sec or higher), contact with falling snow, or freezing conditions requires further measures.			Standard		
Can be turned on or off via the intelligent touch panel.			ndard Equipm		
	03108111010	03108121010	03108887010	03109803010	03111091010
	03108110010	03108120010	03108881010	03109802010	02104017010
Particulate is not taken account.			•		
			•	1	
	0A003386010	0A003433010	0A003805010	0A004173020	0A004626010
Specify the required flow rate and pressure.			•		
Specify the relief pressure.		Sta	ndard Equipm	nent	
		Sta	ndard Equipm	nent	
Standard chiller port size, brass or stainless steel.			<b>*</b>		
Standard chiller port size, brass or stainless steel.			<b>*</b>		
			<b>*</b>		
Filtration Rating: 100 µm (5 µm, 10	04100489010		_		<b>*</b>
μm, 20 μm, and 50 μm are available as special order options.)	_	04100491010	-	_	<b>*</b>
*Operate at or below 0.5 MPa.		_	041004	490010	<b>*</b>
	04100614010			_	
Water Quality: 10 μS/cm or lower	-	04100597010		_	_
		_	041004	437010	04100437010
Including electrical conductivity gauge and flow regulating valve.			04100522010	)	
			4 Voltages		
These voltages require an external transformer. (Sold separately)			•		
	Curren	t Sensitivity : 30 mA		Current Sensi	tivity: 100 mA
Action to be taken after recovery can be enabled or disabled via the intelligent touch panel.		Sta	ndard Equipm	nent	
Can be enabled or disabled via the intelligent touch panel.		Sta	ndard Equipm	nent	
The relay action can be set to ON or OFF via the intelligent touch panel.		Sta	ndard Equipm	nent	
Can be set via the intelligent touch panel.		Sta	ndard Equipm	nent	
The audible alarm can be enabled or disabled via the intelligent touch panel.		Sta	ndard Equipm	nent	

# RKE-B Air-Cooled Series Equipment (Standard / Optional) List

		Function
		Item Detail
	Independent Pump Operation / Control Setting	Pump-only operation can be enabled/disabled via the main unit, remote control, external communications signal, or the remote switch.
	Settings Lock Setting	Control from each of the following can be enabled or disabled: Main Unit, Remote Control, or External Communications Signal.
	Liquid (Chilled Water) Temp Upper/ Lower Limit Warning Option	The method of abnormal liquid (chilled water) temperature detection can be selected. Can enable or disable the alarm and standby sequence for relative value and absolute value alarms.  * Regarding the standby sequence, the alarm will be output after startup until the liquid temperature has initially reached a normal value and then later goes outside the normal range.
	Liquid (Chilled Water) Temp Upper/Lower Limit Warning / Absolute Value Upper Limit	The warning will occur if the water temperature goes above this set temperature regardless of the actual set water temperature.  Will be active when the "Liquid (Chilled Water) Temperature Upper/Lower Limit Warning"  Absolute Value has been selected.
	Liquid (Chilled Water) Temp Upper/Lower Limit Warning / Absolute Value Lower Limit	The warning will occur if the water temperature goes below this set temperature regardless of the actual set water temperature.  Will be active when the "Liquid (Chilled Water) Temperature Upper/Lower Limit Warning" Absolute Value has been selected.
SS	Time Elapsed Warning: Time Setting	A warning will be output if the select time is exceeded. This will be useful, for example, maintenance timing management. The unit can continue to operate when this occurs.
Control Specs	Intelligent Touch Panel Display Functions	Time and Date Display (Year/Month/Date/ Hour:Min (Day)) / Measured Water Temperature, Set Water Temperature, and a graph of the measured water temperature.)  Parameter Mode Display / Water Pressure • Flow Rate • Discharge Pump Operating Frequency and Operating Conditions Display. Japanese • English • Chinese Display (Selectable)
מ	Remote Control	By connecting the remote control unit, the main unit can be operated and controlled (limited control) and operating parameters can be displayed on the Intelligent Touch Panel from an area away from the main unit.
Supply	Communications Functions	As many as 32 chiller units can be connected via RS-422A or RS-485.  USB connection is also possible to 1 unit. Note that USB operation cannot be combined with RS422/485 operation.
LOWG!	Communications Software	Starting and stopping of operation, and monitoring of changing water temperature is possible via PC.
<u>.</u>	Communications Device Address	Enables communications functions and selects the address number of the unit when multiple units are connected together.  Units can be set with address values from 0 to 31 as desired.
	Settings Lock	Changes to the water temperature setting and other parameter settings can be locked out.
	Temperature Warning Signal Output Option	Determines the open/closed state of contacts when a temperature warning signal is present.
		Operation Signal Terminal Block *1
		Alarm Signal Terminal Block *1
	External Signal Operation	Remote Operation (No-voltage contacts) *2
		Remote Operation (24 Vdc input) *2 Only available as factory installed options.
		Remote Operation (200 Vac input) *2 Only available as factory installed options.
		2 freewheeling casters with lock, 2 freewheeling casters without lock
	Casters	With lock
		With leveling foot
	External Surface Coating	Polyester resin, min. 30 µm
	Thickness	Polyester resin, min. 45 μm (Salt-corrosion prevention spec.)
	Color Designation * Specify the color designation	
Otner	as a JPMA No. or Munsell No (including a color sample).	
	Packaging for Export	Basic plywood packaging
	Water Temperature Control Percision	±0.1 °C
	Heating Functionality	Used to raise the temperature during unit startup. (Built-in 200 Vac electric heater.)  * ON/OFF control to the set liquid temperature minus 2 ±0.5 °C.
	Inspection Manual	Japanese English
	Took Deputts Ob and	Japanese
	Test Results Chart	English
	Initial Inspection	for the temperature warning signal *2. There are 2 operating modes unit operation, and numb-only operation, *3. Comes as

<sup>&</sup>lt;Please Note> \*1. In addition, there are contacts for the temperature warning signal. \*2. There are 2 operating modes — unit operation, and pump-only operation. \*3. Comes as standard equipment on G-2 spec models only. \*4. Also available as optional equipment from the manufacturer. \*5. Please consult your dealer if high precision control is required even under low loads (the minimum amount of heat required to maintain inverter control).

RKE-B Series

		- 011-	Site ilistalleu v	optional items (	Model Nullib	ei) <b>–</b> - S	Decial Order
			Model Ai	r-Cooled (RKE	Series)		
Comments	3750B-V	5500B-V	7500B-V		15000B-V	22000B-V	30000B-V
Can be enabled or disabled via the intelligent touch panel.		Standard Equipment					
Can be enabled or disabled via the intelligent touch panel.			Sta	ndard Equipme	ent		
Can be set from the intelligent touch panel.	Standard Equipment						
Water temperature setting can be set from the intelligent touch panel.	Standard Equipment						
Water temperature setting can be set from the intelligent touch panel.	Standard Equipment						
The number of hours (1 h to 30,000 h) can be set from the intelligent touch panel.			Sta	ndard Equipme	ent		
			Sta	ndard Equipme	ent		
Max. wiring length: 20 m		03107963010		0310894	49010	031110	017010
Max. wiring length: 50 m		03107963020		0310894	49020		017020
Max. wiring length: 100 m		03107963030		0310894	49030	031110	017030
	Standard Equipment						
			04105970010				-
	Standard Equipment						
Can enable or disable setting changes from the intelligent touch panel.			Sta	ndard Equipme	ent		
The type of relay output (ON/OFF) when an alarm condition occurs can be selected from the intelligent touch panel.		$\Delta / \perp$	1	ndard Equipme			
No-voltage contacts		V 4	Sta	ndard Equipme	ent V —		
Voltage output (200 V output)				<b>•</b>			
No-voltage contacts			Sta	ndard Equipme	ent		
Voltage output (200 V output)  Max. wiring length: 20 m (w/o cable)			Sto	ndard Equipme	ont		
Max. wiring length: 100 m			Sia		311L		
Max. wiring length: 100 m				<u> </u>			
Max. wiring length: 100 m				<u> </u>			
Max. wiring length: 20 m				•			
Max. wiring length: 100 m				•			
<u> </u>	*3			-			
2 free-wheeling casters, 2 fixed casters *4	03108410010	031084	107010			-	
 4 free-wheeling casters *4	03108408010	031084	105010				
4 free-wheeling casters *4	03108409010	031084	106010				
Salt-corrosion prevention spec. (Acrylic resin, min. 45 μm) External screws are stainless steel.		Sta	ndard Equipn	nent		•	
Condenser and refrigerant piping are treated with a corrosion-resistant coating.	•						
Acrylic resin coating, at least 15 µm thick	•						
For other paint / coatings:	<b>*</b>						
Please consult your dealer for details regarding JIS standard packaging.	•						
*5	Standard Equipment						
Heating output: Selectable among 2 / 3 / 4 / 5 kW, or 5 kW × 2				<b>*</b>			
				•			
				•			
				*			
				<b>—</b>			

# RKE-B Water-Cooled Series Equipment (Standard / Optional) List

		Function
	20 to 400/ other land of head and referen	Item Detail
	30 to 40% ethylene glycol solution	
	Deionized water. Electrical Cond	3 to 35 °C
	Working Liquid (chilled water) Temperature	
	remperature	0 to 35 °C
	Operable Ambient Temp Range	Low temp area spec.: -20 to 45 °C (air cooled), 2 to 45 °C (water cooled)
		High temp area spec.: to 50 °C Requires Distribution Panel High-Temperature Set  This function operates the discharge pump in order to prevent water temperature drops and freezing
ment	Freeze-Prevention Mode	during winter months when unit operations is stopped.  When enabled, the discharge pump will operate when the water temperature falls to 3 °C or below.
ng Environment	Warm Up Mode	This function will automatically operate the discharge pump when the unit is otherwise not operating when the ambient temperature is low, for example during winter months, in order to prevent the water temperature from dropping too much and in order to help maintain the set water temperature. When this mode is enabled, the water temperature can be set within the temperature range of 10 °C to 35 °C as desired.
Operating	Low Noise Mode *2	This function will limit the upper speed of the fan and the fan ventilation noise level will be decreased.
Ope	Outside Installation	IPX4 Equiv. Rating
	Snow Protection Mode	When enabled, and when the unit is stopped, the fan will periodically and automatically start in order to blow fallen snow from the upper exhaust port.
	Snow Protection Hood	Prevents falling snow from entering the fan intake.
	Wind Shield	Consider a wind speed of 8 m/s or higher as a guideline.
	Cleanroom (Leakage Alarm Spec.)	In addition to the standard specification, leakage sensors, pressure resistant piping, refrigerant piping insulation, and water piping insulation are added.
	Water Leakage Detection	Leak detector built-in.
	Vibration Reducing Base	Reduces transmission of vibration from the chiller.
	Discharge Pump Specs.	High flow rate pump built-in. Can replace the built-in high pressure pump.
	Relief Valve (Pressure valve)	Can provide equipment-side pressure protection.
	Water Tank Water-Level Alarm (Lower limit alarm)	Used to avoid water shortages due to evaporation.
	Water Supply Port Open/Close	A ball tap is provided in the water tank in order to maintain a uniform water level.
	Trater supply 1 of speningloss	A ball valve is added to the water supply port.
cuit	Chilled Water Inlet/Outlet Open/	Gate valves are added to the chilled water inlet and outlet ports.
Ş	Close	Compression fittings are added to the chilled water inlet and outlet ports.
Water Circuit	Chilled Water Circuit Water	Water Filter "A" Assembly
	Filter	Water Filter "B" Assembly
Chilled		Water Filter "C" Assembly  Water Purifier "C" Assembly
	Deionized Water Equipment for	Water Purifier "D" Assembly
	Chilled Water Circulation Circuit	Water Purifier "E" Assembly
	Deionized Water Equipment for Chilled Water Supply and Supply Circuits	Purification assembly for supply water.
	Cooling Water (Condenser	Gate valves are added to the cooling water inlet and outlet ports.
	circuit) Inlet/Outlet Open/Close	Compression fittings are added to the cooling water inlet and outlet ports.
S		3 voltages : Three-phase 200 V (50/60 Hz), Three-phase 220 V (60 Hz)
Specs	Primary Power Supply Voltage	Three-phase 230 V (50 Hz), 380 V / 400 V / 415 V / 440 V / 480 V (50/60 Hz)
	Overload Safety Devices	The unit comes with a built in multipurpose overload and short circuit protection breaker.
Control	Power Outage Recovery Operation Settings	Can choose the recovery pattern after power outage. (Manual recovery / Automatic recovery / Remote operation priority)
y and	Operation Action Settings	Can enable or disable operation from among the main unit, remote control, external communications, or remote switch.
Supply	Alarm Signal Output Options	Can choose the state of contacts of the remote alarm signal output. (Contacts either ON or OFF during alarm condition.)
Power S	Action on Compressor Related Alarm	In cases where an alarm signal has been generated, this setting allows the user to choose whether the unit will completely shut down or if components that are able to operate will continue to do so.
P	Audible Alarm Enable/Disable	Audible alarm can be enabled or disabled for each audible alarm or warning.
*1	Note that there will be a 100/ reduction i	n cooling capacity, *2. Note that there will be may 20% reduction in cooling capacity, *3. Copper alloy is used for

<sup>\*1.</sup> Note that there will be a 10% reduction in cooling capacity. \*2. Note that there will be max. 20% reduction in cooling capacity. \*3. Copper alloy is used for wetted parts on standard units.

= On-Site Installed Optional Items (Model Number)	<b>♦</b>	= Special Order
on one metalled optional from (medal frame)	•	op 0 0.00.

		Mode	Water-Cooled (RKE	Series)		
Comments	3750B-VW 5500B-VW 7500B-VW 11000B1-VW 15000B-VW					
Cannot be mixed with deionized water.			Operation Possible	<u> </u>		
Wetted parts are copper-free. *3	<b>◆</b>					
			Standard			
Please operate with a 30% to 40% solution of industrial-use ethylene glycol.  Be careful of freezing at low temperatures as well	Standard					
as abnormal temperature rises due to placement			Standard	I		
in direct sunlight.	04105977020	0410	06046020	_	04107734010	
Can be enabled or disabled via the intelligent touch panel.  * Cannot be used at the same time as the warming up mode.			Standard Equipmer	nt		
Can be enabled or disabled via the intelligent touch panel.  * Cannot be used at the same time as the freeze-prevention mode.			Standard Equipmer	nt		
Can change between normal or low operation modes via the intelligent touch panel.  Installation in direct sunlight, strong wind (8 m/sec or higher), contact			-			
with falling snow, or freezing conditions requires further measures.			Standard			
Can be turned on or off via the intelligent touch panel.			_			
			-			
Particulate is not taken account.			<b>*</b>			
			•			
Openit the section of	0A003386010	UAUC	03433010	0A003805010	0A003805010	
Specify the required flow rate and pressure.			<u> </u>			
Specify the relief pressure.						
			Standard Equipmen	nt 🗸		
			Standard Equipmen	nt		
Standard chiller port size, brass or stainless steel.			<b>*</b>			
 Standard chiller port size, brass or stainless steel.			•			
			<b>*</b>			
Filtration Rating: 100 µm (5 µm, 10	04100489010			_		
μm, 20 μm, and 50 μm are available as	_	0410	00491010	_	_	
special order options.)				041004	490010	
	04100614010			_		
 Water Quality: 10 μS/cm or lower	_	0410	00597010	_		
				041004	437010	
Including electrical conductivity gauge and flow regulating valve.			04100522010			
 Standard chiller size, brass or stainless steel.			<b>*</b>			
			<b>*</b>			
			3 Voltages			
These voltages require an external transformer. (Sold separately)			<b>*</b>			
	Cu	rrent Sensitivity:	30 mA	Current Sensi	tivity: 100 mA	
Action to be taken after recovery can be enabled or disabled via the intelligent touch panel.			Standard Equipmer	nt		
Can be enabled or disabled via the intelligent touch panel.			Standard Equipmer	nt		
The relay action can be set to ON or OFF via the intelligent touch panel.			Standard Equipmer	nt		
Can be set via the intelligent touch panel.			Standard Equipmer	nt		
The audible alarm can be enabled or disabled via the intelligent touch panel.			Standard Equipmer	nt		

# RKE-B Water-Cooled Series Equipment (Standard / Optional) List

		Function
		Item Detail
	Independent Pump Operation / Control Setting	Pump-only operation can be enabled/disabled via the main unit, remote control, external communications signal, or the remote switch.
	Settings Lock Setting	Control from each of the following can be enabled or disabled: Main Unit, Remote Control, or External Communications Signal.
	Liquid (Chilled Water) Temp Upper/ Lower Limit Warning Option	The method of abnormal liquid (chilled water) temperature detection can be selected. Can enable or disable the alarm and standby sequence for relative value and absolute value alarms.  * Regarding the standby sequence, the alarm will be output after startup until the liquid temperature has initially reached a normal value and then later goes outside the normal range.
	Liquid (Chilled Water) Temp Upper/Lower Limit Warning / Absolute Value Upper Limit	The warning will occur if the water temperature goes above this set temperature regardless of the actual set water temperature.  Will be active when the "Liquid (Chilled Water) Temperature Upper/Lower Limit Warning"  Absolute Value has been selected.
	Liquid (Chilled Water) Temp Upper/Lower Limit Warning / Absolute Value Lower Limit	The warning will occur if the water temperature goes below this set temperature regardless of the actual set water temperature.  Will be active when the "Liquid (Chilled Water) Temperature Upper/Lower Limit Warning"  Absolute Value has been selected.
SCS	Time Elapsed Warning: Time Setting	A warning will be output if the select time is exceeded. This will be useful, for example, maintenance timing management. The unit can continue to operate when this occurs.
Control Specs	Intelligent Touch Panel Display Functions	Time and Date Display (Year/Month/Date/ Hour:Min (Day)) / Measured Water Temperature, Set Water Temperature, and a graph of the measured water temperature.)  Parameter Mode Display / Water Pressure • Flow Rate • Discharge Pump Operating Frequency and Operating Conditions Display. Japanese • English • Chinese Display (Selectable)
and	Remote Control	By connecting the remote control unit, the main unit can be operated and controlled (limited control) and operating parameters can be displayed on the Intelligent Touch Panel from an area away from the main unit.
Supply	Communications Functions	As many as 32 chiller units can be connected via RS-422A or RS-485.  USB connection is also possible to 1 unit. Note that USB operation cannot be combined with RS422/485 operation.
Power (	Communications Software	Starting and stopping of operation, and monitoring of changing water temperature is possible via PC.
Po	Communications Device Address	Enables communications functions and selects the address number of the unit when multiple units are connected together.  Units can be set with address values from 0 to 31 as desired.
	Settings Lock	Changes to the water temperature setting and other parameter settings can be locked out.
	Temperature Warning Signal Output Option	Determines the open/closed state of contacts when a temperature warning signal is present.
		Operation Signal Terminal Block *1
		Alarm Signal Terminal Block *1
	External Signal Operation	Remote Operation (No-voltage contacts) *2
		Remote Operation (24 VDC input) *2 Only available as factory installed options.
		Remote Operation (200 VAC input) *2 Only available as factory installed options.
		2 freewheeling casters with lock, 2 freewheeling casters without lock
	Casters	With lock
		With leveling foot
	External Surface Coating	Polyester resin, min. 30 µm
	Thickness	Polyester resin, min. 45 μm (Salt-corrosion prevention spec.)
	Color Designation * Specify the color designation	
Other	as a JPMA No. or Munsell No (including a color sample).	
_	Packaging for Export	Basic plywood packaging
	Water Temperature Control Percision	±0.1 °C
	Heating Functionality	Used to raise the temperature during unit startup. (Built-in 200 VAC electric heater.)  * ON/OFF control to the set liquid temperature minus 2 ±0.5 °C.
	Inspection Manual	Japanese
		English Japanese
	Test Results Chart	English
	Initial Inspection	for the temperature warning signal *2. There are 2 operating modes unit operation, and numb-only operation. *3. Comes as

<sup>&</sup>lt;Please Note> \*1. In addition, there are contacts for the temperature warning signal. \*2. There are 2 operating modes — unit operation, and pump-only operation. \*3. Comes as standard equipment on G-2 spec models only. \*4. Also available as optional equipment from the manufacturer. \*5. Please consult your dealer if high precision control is required even under low loads (the minimum amount of heat required to maintain inverter control).

			Model Water-Cooled (RKE	Series)
	Comments	3750B-VW	5500B-VW 7500B-VW	11000B1-VW 15000B-VW
	be enabled or disabled via the ligent touch panel.		Standard Equipmer	nt
Can	be enabled or disabled via the		Standard Equipmer	nt
	be set from the intelligent touch	Standard Equipment		
<u>'</u>	er temperature setting can be set			
from	the intelligent touch panel.		Standard Equipmer	nt
from	er temperature setting can be set the intelligent touch panel.		Standard Equipmer	nt
The i	number of hours (1 h to 30,000 h) can et from the intelligent touch panel.		Standard Equipmer	nt
			Standard Equipmer	nt
	. wiring length: 20 m		03107963010	03108949010
	. wiring length: 50 m		03107963020	03108949020
Max.	. wiring length: 100 m		03107963030	03108949030
		Standard Equipment		ht
		04105970010		
0	anable or disable settion absorbed	Standard Equipment		ht
from	enable or disable setting changes the intelligent touch panel.	Standard Equipment		nt
The typoccurs	pe of relay output (ON/OFF) when an alarm condition can be selected from the intelligent touch panel.	$HI \setminus$	Standard Equipmer	
	voltage contacts		Standard Equipmer	nt V
	age output (200 V output)		<b>•</b>	
	voltage contacts		Standard Equipmer	nt
	age output (200 V output)		<b>•</b>	
	wiring length: 20 m (w/o cable)		Standard Equipmer	nt
	. wiring length: 100 m		<b>•</b>	
	. wiring length: 20 m		<b>•</b>	
	. wiring length: 100 m		<u> </u>	
	. wiring length: 20 m		<b>•</b>	
Max.	. wiring length: 100 m		<b>*</b>	
		*3	-	_
	e-wheeling casters, 2 fixed casters *4	03108410010	03108407010	-
	e-wheeling casters *4	03108408010	03108405010	-
	e-wheeling casters *4	03108409010	03108406010	-
	orrosion prevention spec. (Acrylic resin, min. 45 µm)		Standard Equipmer	nt
Conder	nser and refrigerant piping are treated with a corrosion- nt coating.		<b>*</b>	
Acryl	lic resin coating, at least 15 µm thick	<b>◆</b>		
	other paint / coatings use consult your dealer for details	<b>*</b>		
regar	rding JIS standard packaging.	<b>◆</b>		
*5			Standard Equipmer	nt
Heat / 4 /	ting output: Selectable among 2 / 3 5 kW, or 5 kW × 2		<b>*</b>	
			<b>♦</b>	
			<b>*</b>	
			<b>*</b>	
			<b>♦</b>	

# CE Marking Certified Chillers RKE-B (Air-Cooled Series)

### CE Certified Air-Cooled Models

IPX4 Equiv. Rating Splash-proof

Cooled Cooling 12.2 to 48.0 kW Capacity Operable -20 to 45 °C **Ambient Temp** Operable Liquid 3 to 35 °C Temp Range Temp Control ±0.1 °C Precision

See page 7 for external dimensions.


### Specifications




Model			RKE3750B-V-CE G1 / G2(w/ casters)	RKE5500B-V-CE	RKE7500B-V-CE	RKE11000B-V-CE	RKE15000B-V-CE		
υ δ	Cooling Capacity *1		kW	12.2	20.3	25.0	37.2	48.0	
Performance Specifications	Heating Capacity *8		kW	2.8	3	.7	8.0	10.0	
ma	Operable Ambient Tempo		°C		-20 1	to 45 (w/ option: -20 to	50)		
cifi	Operable Liquid Tempera	ature Range	°C		3 to	35 (w/ brine: 0 to 35)	*7		
Per l	Control Precision *4				±0.1 °C (	Energy saving mode:	±2.0 °C)		
ш 0	Operating Flow Rate		L / min	15 to 60	60 to	170	100 t	o 230	
LS L	Power Source *2		V (Hz)		Three-pl	nase 200 to 220 ±10%	(50/60)		
Power pecifications	Power Consumption *1		kW	5.4	9.8	10.2	14.4	18.1	
Power	Electric Current *1		Α	16.5	30.1	33.5	47.0	56.3	
A	Power Capacity *3		kVA	7.0	11.0	11.8	19.5	22.0	
Ş	Breaker Capacity *6		Α	30 50			75	100	
Opera	ation Control Method	T	T	Compressor speed control					
	Compressor	Construction	` <u>_</u>	Fully sealed rotary type (inverter driven)  Fully sealed scroll type (inverter driven)				ype (inverter driven)	
l "	Compressor	Output	kW	1.7	3.0	4.6	7.46	11.19	
iii iii	Condenser			Fin and tube forced air cooling					
) Je	Heat Exchanger	Construct	ion	Plate type heat exchanger					
l Ħ	rieat Exchanger	Materia	al	SUS316 (Brazing: Cu)					
Equipment Details	Discharge Pump	Construct	ion		Multista	ge centrifugal immers	ion type		
₫	Discharge Fullip	Output	kW	1.1 (Inverter driven)	1.5 (Inver	ter driven)	4.0 (Inver	ter driven)	
1 5	Fan Motor	otor Output I		0.4 (Inverter driven)	0.75 (Inve	rter driven)	0.4 × 2 (Inv	erter driven)	
-	Water Tank Capacity		L	Approx. 60	Appro	ox. 90	Appro	x. 100	
	Refrigerant					R-410A			
Exteri	nal Dimensions (H×D×W)		mm	G1:1410 (G2:1536) × 752 × 720	1700 × 8	54 × 870	1700 × 854 × 1380	1800 × 854 × 1610	
	Mass (dry weight)		kg	G1:200 / G2:205	280	290	415	460	
Opera	ating Noise Level (50/60 H	łz) *5	dB	60	6	3	69	68	

<sup>\*1.</sup> Operating conditions: Chilled water temp: 20 °C, Cooling water temp: 32 °C (water cooled units only), Ambient temp: 32 °C. Cooling capacity is at least 95% of listed figures. \*2. Source voltage phase unbalance should be less than ±3%. \*3. The figure noted is when operating at the highest capacity in the normal operating range. \*4. Continuous current load fluctuation within ±10%, and with stable ambient temp and power supply, etc. Does not include starting times or when the cooling load is too small, in which case the compressor may cycle on and off.

### Cooling Capacity






<Conditions> • Chilled Liquid : Water • Flow Rate : RKE3750B-V(W)

- 43 L/min RKE5500B-V(W) • 7500B-V(W) 125 L/min RKE11000B-V(W) 140 I /min RKE15000B-V(W) 200 L/min
- Ambient Temperature : 32 °C
  Cooling Water Temperature : 32 °C

### Cooling Water Flow Rate (For the water cooled condenser)



- Actual cooling water flow rate will depend on the water temperature.
- \* Ensure the required quantity of water as shown in the graphs below.

<sup>\*5.</sup> Operating noise levels are from a position of 1 m in front of the unit and at a height of 1 m. \*6. Unit comes with a built-in multi-purpose overload and short circuit protection breaker. \*7. For liquid temperature settings of 0 to 3 °C, use a 30 to 40% solution of industrial-use ethylene glycol. \*8. At time of startup only. Will differ depending on ambient temperature

Note 1: The recommended liquid (chilled water) that can be used is either clean water or a 30 to 40% ethylene glycol solution. Note that there will be a 10% reduction in cooling capacity if using a 30 to 40% ethylene glycol solution. Alternatively, if deionized water is to be used, it should have an electrical conductivity of at least 1  $\mu$ S/cm. Note 2: Heat output from the unit (in kW) is approx. 1.3 times that of the cooling capacity.(Air cooled models)

# CE Marking Certified Chillers RKE-B (Water-Cooled Series)

Low Voltage Directive (2014/35/EU)

CE Certified Water-Cooled Models

Compliance Standard IPX4 Equiv. Water Cooled Rating Splash-proof Cooling 14.1 to 48.0 kW Capacity Operable 2 to 45 °C **Ambient Temp** Operable Liquid 3 to 35 °C Temp Range Temp Control ±0.1 °C Precision

See page 10 for external dimensions.

# EU60204-1:2006/A1:2009 RoHS Directive (2011/65/EU) EN5058:2012 EN61000-6-2:2005 EN61000-6-4:2007+A1:2011 EN61000-6-2:2005 EN61000-6-4:2007+A1:2011

EMC Directive (2014/30/EU): Industrial Environment

### Specifications


	Model			RKE3750B-VW-CE G1 / G2 (w/ casters)	RKE5500B-VW-CE	RKE7500B-VW-CE	RKE11000B-VW-CE	RKE15000B-VW-CE	
	Cooling Capacity *1		kW	14.1	23.4	27.3	43.0	48.0	
Sus	Heating Capacity *8		kW	2.8	3.0	3.1	9.1	10.0	
an atic	Operable Ambient Temp	erature Range	°C		2 to 45 (w/ or	otion: 2 to 50)		2 to 45	
1 [2]	Cooling Water Temperat	ure Range	°C			5 to 45			
l Sign	Operable Liquid Temper	ature Range	°C		3 to	35 (w/ option: 0 to 35	5) *7		
Performance Specifications	Control Precision *4					(Energy saving mode:	±2.0 °C)		
	Operating Flow Rate		L/min	15 to 60		170		o 230	
Power Specifications	Power Source *2		V (Hz)		Three-phase 20	00 ±10% (50) / 200 to	220 ±10% (60)		
atio l	Power Consumption *1		kW	5.1	8.8	10.1	12.7	15.3	
li o ∈	Electric Current *1		Α	19.2	31.8	33.0	41.0	48.2	
P 29	Power Capacity *3		kVA	8.0	12.2	12.6	17.5	19.5	
S	Breaker Capacity *6		A	30 50				5	
Opera	ation Control Method		1	Compressor speed control					
	Compressor	Construction			led rotary type (invert	er driven)	Fully sealed scroll t	ype (inverter driven)	
8	Compressor	Output	kW	1.7	3.0	4.6	7.46	11.19	
Equipment Details	Condenser			Double pipe water cooling					
	Heat Exchanger	Construction				ate type heat exchang			
en	Tieat Exchanger	Material		SUS316 (Brazing: Cu)					
1 6	Discharge Pump	Construction				ge centrifugal immers			
l ib		Output	kW	1.1 (Inverter driven)		ter driven)		ter driven)	
Ш	Water Tank Capacity L		L	Approx. 60	Appro	ox. 90	Appro	x. 100	
	Refrigerant					R-410A			
	nal Dimensions (H×D×W)	)	mm	G1:1410 (G2:1536) × 752 × 720	1700 × 8	54 × 870	1410 × 8	54 × 1380	
Unit N	Mass (dry weight)		kg	G1:200/G2:205	G2: 205 280 290		40	05	
Opera	ating Noise Level (50/60 l	Hz) *5	dB	58	5	9	61	59	


- \*1. Operating conditions: Chilled water temp: 20 °C, Cooling water temp: 32 °C (water cooled units only), Ambient temp: 32 °C. Cooling capacity is at least 95% of listed figures. \*2. Source voltage phase unbalance should be less than ±3%. \*3. The figure noted is when operating at the highest capacity in the normal operating range. \*4. Continuous current load fluctuation within ±10%, and with stable ambient temp and power supply, etc. Does not include starting times or when the cooling load is too small, in which case the compressor may cycle on and off.
- \*5. Operating noise levels are from a position of 1 m in front of the unit and at a height of 1 m. \*6. Unit comes with a built-in multi-purpose overload and short circuit protection breaker.
- \*7. For liquid temperature settings of 0 to 3 °C, use a 30 to 40% solution of industrial-use ethylene glycol. \*8. At time of startup only. Will differ depending on ambient temperature and cooling water temperature.


Note 1: The recommended liquid (chilled water) that can be used is either clean water or a 30 to 40% ethylene glycol solution. Note that there will be a 10% reduction in cooling capacity if using a 30 to 40% ethylene glycol solution. Alternatively, if deionized water is to be used, it should have an electrical conductivity of at least 1  $\mu$ S/cm.


### Chilled Water Flow Chart


- \* The illustration shows the actual measured flow rate value when the bypass valve is closed.
- \* Flow rate changes based on inverter frequency
- \* The shaded area indicates the range possible for the adjusted frequency value.
- \* If additives are used, the flow rate characteristics will change due to factors such as the additive used, the concentration, fluid temp, etc.











# RKE-A Series (Heavy Duty Models)

Compressor

Inverter Controlled Built-In Discharge Pump

External Warning Alarm Terminals Operation / Alarm / Remote operation

IPX4 Equiv. Rating Splash-proof **HFC Refrigerant** R-407C

Remote Control Panel (Optional)

### **Features**

- 1. Operates with a maximum energy savings of 57%. \* These Orion chillers respond to work loads using the least amount of energy. (\* Compared with HB control models running at a 30% load)
- 2. Highly Precise liquid temperature control possible. The chiller senses the liquid temperature and adjusts the compressor speed accordingly, thus achieving liquid temperature precision control of ±0.2 to ±1.0 °C. (Precision is subject to work loads. Please consult your dealer if high precision control is demanded.)
- Wide range of liquid temperature control. Wide range of liquid temperature control.
- 4. Comes with built-in communications interface as standard equipment.

Allows temperature control via RS232C or RS422 interfaces.





### Specifications

	Madal			Air-Cooled Model	Water-Cooled Model	
Model				RKE18000A-V	RKE18000A-VW	
2 Se	Cooling Capacity (50/60	Hz) *1	kW	57/60	57/60	
and	Operable Ambient Tempo	erature range	°C	-5 to 43	2 to 43	
	Operable Liquid Tempera	ature Range	°C	5 to	35	
Performance Specifications	Control Precision *4			Under high precision setting ±1.0 °C (±0.5 °C durin	0 °C (±0.5 °C during stable load), g stable load, ±2.0 °C during ON/OFF cycle mode)	
SI	Power Source *2		V (Hz)	Three-phase 200 ±10%	(50/60), 220 ±10% (60)	
Power pecifications	Power Consumption (50/6)	0 Hz, 220 V) *1	kW	25.5/28.0, 28.0	23/25, 25	
Power	Electric Current (50/60 H	łz, 220 V) *1	Α	82.2/89.8, 89.8	72/80, 80	
ec. p	Power Capacity *3		kVA	35	32	
Ş	Breaker Capacity		Α	125 *7	125 *7	
	Compressor Output	T	kW	3.0, 7.46	3.0, 7.46	
<u></u>	Condenser		, L	Fin and tube forced air cooling	Double pipe water cooling	
Details	Heat Exchanger	Construction		Plate type he		
Ö	rieat Exchange	Material		SUS316 grade stainless	s steel (brazing: copper)	
en	Discharge Pump	Output	kW	3.2 (invert	er driven)	
Equipment	Discharge Fullip	Flow Rate *5 L/min		200 (Hea	ad: 50 m)	
ji.	Fan Motor Output	Notor Output W		750 × 2 (inverter driven)	-	
Ш	Water Tank Capacity L		L	Approx. 160	Approx. 160	
Refrigerant				R-4		
	nal Dimensions (H×D×W)		mm	1800×960×1720	1580×960×1720	
Unit N	Mass (dry weight)		kg	Approx. 660	610	
Opera	ating Noise Level *5		dB	69	60	


<sup>\*1.</sup> Operation when liquid temp is 20 °C, ambient temp is 32 °C, and cooling water temp. is 32 °C. Cooling capacity is at least 95% of listed figures. \*2. Source voltage phase unbalance should be less than ±3%. \*3. The figure noted is when the equipment is operating at the highest capacity of its normal operating range. \*4. Stable load indicates continued operation with maximum load fluctuations of ±10% of the current load. (However, this is excluding loads in the 25% to 40% range.) Setting can be changed by adjusting parameter F15. (Default setting is the high-precision setting.) \*5. Please operate with a head of 50 m or less. \*6. Operating noise levels are from a position of 1 m in front of the unit and at a height of 1 m. \*7. Unit comes with a built-in multi-purpose overload and short circuit protection breaker. Note 1: Please install the included strainer (40 mesh) to the liquid intake port. Note 2: The recommended liquid (chilled water) that can be used is either clean water or a 30 to 40 % industrial-use ethylene glycol solution. Alternatively, if deionized water is used, it should have an electrical conductivity of at least 1 µS/cm. Note 3: Heat output of the equipment (in kW) is about 1.3 times the cooling capacity. (Air cooled only.) Note 4: RKE18000A-VW model is built to order item.

### Cooling Capacity






### Cooling Water Flow Rate (for condenser)




### Chilled Water Flow Rate


\* Internal (return side) Head Loss: 0.7 m or less.



### External Dimensions (Units: mm)

\*1 : Put the signal lines and communication cables for respective wirings through the holes separate from the power cord hole.





# **RKE-A Series** (Heavy Duty Water-Cooled Models)

Compressor

Inverter Controlled Built-In Discharge Pump

External Warning Alarm Terminals
Operation / Alarm / Remote operation

IPX4 Equiv. Rating Splash-proof **HFC Refrigerant** R-407C

### **Features**

- 1. Operates with a maximum energy savings of 57%. \* Orion chillers respond to work loads using the least amount of energy. (8 Compared with HB control models running at a 30% load)
- 2. Highly precise liquid temperature control possible. The chiller senses the liquid temperature and adjusts the compressor speed accordingly, thus achieving liquid temperature precision control of ±0.2 to ±1.0 °C. (Precision is subject to work loads. Please consult your dealer if high precision control is demanded.)
- 3. Wide range of liquid temperature control. User settings of liquid temperatures between 15 to 30 °C are now possible.
- 4. Adopted for use with environmentally friendly refrigerant. Uses non ozone-depleting R-407C refrigerant.
- 5. Comes with built-in communications interface as standard equipment. Allows temperature control via RS232C or RS422 interfaces. RKE30000A-VW models excluded.





### Specifications

Model				Water-Cooled Models				
				RKE22000A-VW	RKE30000A-VW			
3 g	Cooling Capacity (50/60	Hz) *1	kW	70.0/73.0	96			
ang alio	Operable Ambient Tempe	erature Range	°C	2 to	0 43			
E jij	Operable Liquid Tempera	ature Range	°C	15 t	o 30			
Performance Specifications	Control Precision *4			Under high precision setting ±1.0 °C (±0.5 °C during stable load), under energy-saving setting ±1.0 °C (±0.5 °C during stable load, ±2.0 °C during ON/OFF cyc				
ns	Power Source *2		V (Hz)	Three phase 200 ±10%	(50/60), 220 ±10% (60)			
Power specifications	Power Consumption *1		kW	38.0/40.0, 40.0	43, 43			
	Electric Current *1		Α	125/128, 128	126, 126			
ec P	Power Capacity *3	city *3 kVA		50.0	54			
Sp	Breaker Capacity		Α	175 *6				
	Compressor Output		kW	7.5, 7.46	7.5×2			
<u></u>	Condenser			Double pipe water cooling				
eta	Heat Exchanger	Construction	YT	Plate type he	at exchanger			
	Treat Exchanger	Material	\	SUS316 grade stainles	steel (brazing: copper)			
Equipment Details	Discharge Pump	Output	,		iven pump × 2			
l E	Flow Rate L/m		L/min	Minimum 400	(Head: 50 m)			
Į į	Fan Motor Output		kW	-	-			
Ш	Water Tank Capacity		L	Approx. 250	Approx. 320			
Refrigerant			R-407C					
	nal Dimensions (H×D×W)		mm	1700×1240×2050	1700×1340×2350			
	lass (dry weight)		kg	1100	1420			
Operating Noise Level (50/60 Hz) *5 dB		dB	61	62				

<sup>\*1.</sup> When operating under these conditions: chilled water temperature is 20 °C, ambient temperature is 32 °C, cooling water temperature is 32 °C. Cooling capacity will be at least 95% of the noted figures, \*2. Source voltage phase unbalance should be less than ±3%, \*3. The figure noted is when the equipment is operating at the highest capacity of its normal operating range. \*4. Stable load indicates continued operation with maximum load fluctuations of ±10% of the current load. (However, this excludes cases where the electronic capacity control valve cycles on and off.) The setting can be changed by adjusting parameter F15. (Default value: High-precision setting.) \*5. Operating noise levels are from a position of 1 m in front of the unit and at a height of 1 m. \*6. Unit comes with a built-in multi-purpose overload and short circuit protection breaker. Note 1: Please install the included strainer (40 mesh) to the liquid intake port. Note 2: The recommended liquid (chilled water) that can be used is either clean water or a 30 to 40 % industrial-use ethylene glycol solution. Alternatively, if deionized water is used, it should have an electrical conductivity of at least 1 µS/cm. Note 3: The above two models are built-to-order items.

### Cooling Capacity









- <Conditions>
- •Cooling Water Temperature: 32 °C
- Chilled Liquid: Water

### Cooling Water Flow Rate (for condenser)




### Chilled Water Flow Rate




- 40MMF03.2 pumps
- 2. Internal (return side) Head Loss: 0.7 m or less.
- Flow rate for stand-alone pump operation
  - Flow rate including heat exchanger head loss

### External Dimensions (Units: mm)

\*1: Signal and communications related wiring should not pass through the same hole as power cables.





# RKED Series (Digital Control Models)

Digitally Controlled Built-In Discharge Compressor

Pump

External Warning Alarm Terminals IPX4 Equiv.

Operation / Alarm / Remote operation Rating Splash-proof

**HFC Refrigerant** R-407C

Remote Control Panel (Optional)

### **Features**

- 1. Digital Compressor Control for an Additional 65% in Energy Savings Thanks to our original digital control (LOAD/UNLOAD) technology, we have achieved high-efficiency energy savings across the full range of loads from 0% to 100%.
- 2. Safe and Reliable Design

The RKED Series inherits its primary functionality from ORION chillers which have been receiving high marks from our customers. And thanks to simplified structural components, we've achieved a highly reliable chiller suitable in a wide variety of applications.

3. External communications interface included as standard equipment. Allows temperature control via RS232C or RS422 interfaces.





### Specifications


				Ain Cooled Model	Water Caslad Madel	Air Canlad Madel		
Model				Air-Cooled Model	Water-Cooled Model	Air-Cooled Model		
				RKED2200A-V	RKED2200A-VW	RKED9000A-V		
Performance Specifications	Cooling Capacity (50/	60 Hz) *1	kW	7.9/8.7	9.8/10.4	29.2/31.4		
nan	Operable Ambient Ter	mperature Range	°C	-5 to 43	2 to 43	−5 to 43		
lg ilg	Operable Liquid Temp	erature Range	°C		5 to 35			
ag S	Control Precision *4			±1.0 °	C (during periods of a stable load: ±0	0.5 °C)		
	Power Source *2		V (Hz)	Three	e phase 200 ±10% (50/60), 220 ±10%	% (60)		
Power secifications	Power Consumption (50/60 Hz, 220 V) *1		kW	3.5/4.6, 4.6	2.9/3.7, 3.7	14/17, 17		
Pow	Electric Current (50/60 Hz, 220 V) *1			12.9/15.2, 150	11.3/12.8, 12.6	45/52, 52		
l g	Power Capacity *3		kVA	6.9		20		
	Breaker Capacity		Α	, 3	0	75 *7		
	Compressor Output		kW		238	7.09		
	Condenser	1		Fin and tube forced air cooling	Double pipe water cooling	Fin and tube forced air cooling		
is is	Heat Exchanger	Construction		Plate type heat exchanger				
ets	Tieat Exchange	Material			ppper)			
1 🗅		Output	kW		75	2.2		
Equipment Details	Discharge Pump *5	Flow Rate	L/min		/43	60/125		
l d		(50/60 Hz)		(	: 50 m)	(Head: 50 m)		
l ä	Fan Motor Output		W	100 (inverter driven)	-	750 (inverter driven)		
ш					Approx. 95			
Refrigerant Control Method				Electronic	expansion valve (controlled by stepp	oing motor)		
	Refrigerant			1110	R-407C	1000 050 1000		
	nal Dimensions (H×D×W	/)	mm	1440×730×960		1800×850×1200		
	Mass (dry weight)	011 ) +0	kg	240	230	435		
Opera	ating Noise Level (50/6	0 Hz) *6	dB	62/67	59/63	69/71		

<sup>\*1.</sup> When operating under these conditions: chilled water temperature is 20 °C, ambient temperature is 32 °C, cooling water temperature is 32 °C. Cooling capacity is at least 95% of listed figures. \*2. Source voltage phase unbalance should be less than ±3%. \*3. The figure noted is when the equipment is operating at the highest capacity of its normal operating range. \*4. Stable load indicates continued operation with maximum load fluctuations of ±10% of the current load. \*5. The capacity figures listed represent just one point on this model's flow-rate/head characteristic curve. Pumps differ between models: for model specific details, please refer to the pump characteristic curves. \*6. Operating noise levels are from a position of 1 m in front of the unit and at a height of 1 m. 7. Unit comes with a built-in multi-purpose overload and short circuit protection breaker. Note 1: The recommended liquid (chilled water) that can be used is either clean water or a 30 – 40.% industrial-use ethylene glycol solution. Alternatively, if deionized water is used, it should have an electrical conductivity of at least 1 µS/cm. Note 2: Please install the included strainer (40 mesh) to the liquid infake port. Note 3: Heat output of the equipment (in kW) is about 1.3 times the cooling capacity. (air cooled models only)


### Cooling Capacity









### Cooling Water Flow Rate (for condenser)



### Chilled Water Flow Rate





\* To estimate the evaporator head loss, the external piping resistance to the evaporator head loss and read the flow rate and pressure accordingly.

Flow Rate for Pump-Only Operation


----- 60 Hz ----- 50 Hz


30 HZ


--- Heat exchanger head loss

### External Dimensions (Units: mm)

\*1: Signal lines and power cords should be routed through different access holes.







### Remote Control • Communications Software • Wind Shield • Snow Protection Hood

Optional Equipment and Parts for Chillers & Unit Coolers

### **RKE-A and RKED Series**

### **Communications Software**



Part Name	Part Number	Applicable Models
Communications Software	04091273010	RKE *1 and RKED Series

<sup>\*1.</sup> Except RKE30000A-VW

### Remote Control (Wired)







Remote Control Cable Assembly


### Remote Control (Wired) Set


The Remote Control (Wired) Set does not come with a cable. Please order the Remote Control Cable Assembly.

Part Name	Part Number	Applicable Models
Remote Control (Wired) Set A	04100607010	RKED2200A-V(W) RKE18000A-V(W)
Remote Control (Wired) Set B	04100608010	RKED9000A-V RKE22000A-VW
Remote Control Cord Assembly (20 m)	04100541010	DKE *4
Remote Control Cord Assembly (50 m)	04100541020	RKE *1 and RKED Series All Models
Remote Control Cord Assembly (100 m)	04100541030	TTT X

Chiller models made before April 2006 require a CPU replacement in order to use this remote control. Please inform your dealer of the chiller serial number before

### Wind Shield









Part Name	Part Number	Applicable Models
Wind Shield Assembly	03091229010	RKED2200A-V
	03091230010	RKED9000A-V
	03091363010	RKE18000A-V

### Snow Protection Hood



\* Please arrange a special-order number for items used with RKE22000 and 30000A-V

	Part Name	Part Number	Applicable Models
5	Snow Protection Hood	03091238010	RKED2200A-V
	Assembly	03091238020	RKED9000A-V RKE18000A-V (2 hoods)

### **RKE-B Series**

### • Chiller Communications Software



Part Name	Part Number	Applicable Models
Communications Software	04105970010	RKE3750B-V(W) RKE5500B-V(W) RKE7500B-V(W) RKE11000B1-V(W) RKE15000B-V(W)

### • Remote Control (Wired)





Remote Control Sets include cables. The set model number differs depending on the cable length.

	Remote Control (Includes cable)	Part Number	Applicable Models
	Max. cable length: 20 m	03107963010	RKE3750B-V(W)
	Max. cable length: 50 m	03107963020	RKE5500B-V(W)
	Max. cable length: 100 m	03107963030	RKE7500B-V(W)
	Max. cable length: 20 m	03108949010	
	Max. cable length: 50 m	03108949020	RKE11000B1-V(W) RKE15000B-V(W)
ı	Max. cable length: 100 m	03108949030	
	Max. cable length: 20 m	03111017010	
/	Max. cable length: 50 m	03111017020	RKE22000B-V RKE30000B-V
	Max. cable length: 100 m	03111017030	

### Wind Shield

The Wind Shield is used for outdoor installations.



Part Name	Part Number	Applicable Models
Wind Shield	03108110010	RKE3750B-V
	03108120010	RKE5500B-V RKE7500B-V
	03108881010	RKE11000B1-V
	03109802010	RKE15000B-V
	02104017010	RKE22000B-V RKE30000B-V

### Snow Protection Hood

The Snow Protection Hood supports outdoor installations in snowy regions.



Part Name	Part Number	Applicable Models
	03108111010	RKE3750B-V
	03108121010	RKE5500B-V RKE7500B-V
Snow Protection Hood	03108887010	RKE11000B1-V
	03109803010	RKE15000B-V
	03111091010	RKE22000B-V RKE30000B-V

purchasing. \*1. Except RKE30000A-VW

# **Water Filtering Equipment**

Helps to prevent clogging within the water circuit of chillers and other equipment. Can also be used as a pre-filter for water purification equipment.

### **Features**

- 1. Wall mount type for easy cartridge replacement.
- 2. Includes ball valves as standard equipment.
- 3. Optional stand mount available.





### ■ Specifications

	Model		Water Filter: A-Assembly	Water Filter: B-Assembly	Water Filter: C-Assembly	
	Part number		04100489010	04100489010 04100491010 04100490010		
Applicable Mod	dels		RKED2200A-V(W) RKE5500B-V(W) RKE11000B1-V(W) *2 RKE3750B-V(W) RKED9000A-V RKE15000B-V(W) *2			
Operating	Maximum Working Pressure	MPa		0.5		
Ranges	Maximum Working Temperature	°C		50		
Performance	Degree of Filtration	μm		100		
Specifications	Initial Element Pressure Loss	MPa	0.02 (flow rate 43 L/min)	0.02 (flow rate 125 L/min)	0.02 (flow rate 140 L/min)	
Main	Piping Connection Size		Rc1/2 (Rc1) *1	Rc1	Rc1•1/4	
Dimensions	Mass	kg	6.3	8.0	10.0	
Element Model Number SD-100-250-B SD-100-500-B			0-500-B			
Element Part N	Number	· F	40605000410 40605000400			
O-ring Part Nu	g Part Number XB673167023					

Note: Configuration for use with RKE18000A-V(W) models and higher are special order items.

### **■ External Dimensions**






Model	Water Filter:A-Assembly	Water Filter:B-Assembly	Water Filter:C-Assembly
А	(435)	(405)	(449)
В	458	708	715
С	197	197	197
D	312	562	565
E	103	103	103
F	423 min.	673 min.	680 min.
G	Rc1/2	Rc1	Rc1•1/4

### ■ Stand Mount (Optional) (Part No.: 04100569010)

- Works with all filters, Deionizer D-Assembly, and Deionizer E-Assembly.
- 2 filters can be mounted one over the other on a single stand allowing for space saving configurations, such as having a water filter mounted over an ion exchange filter.





(Units:mm)

<sup>\*1.</sup> Can be replaced by removing the 1×1/2B adaptor bushing. \*2. Operate with a chilled water pressure of 0.50 MPa or below.

For circulating water setups (Installed in a bypass configuration, it can help protect against rising electrical conductivity within the water circuit.)



Model		Deionizer C-Assembly	Deionizer D-Assembly	Deionizer E-Assembly	
Part Number		04100614010	04100597010	04100437010	
Applicable Models		RKED2200A-V(W) RKE3750B-V(W) RKE09000A-V		RKE11000B1-V(W) RKE15000B-V(W) RKE18000A-V(W)	
Ion Exchange Resin		RDI-150	DI-0-10BB	DI-0-20BB	
Ion Exchange Resin Part Number		0A001387000	0A001108000	0A001017000	
Processing Capacity *1,2	L	Approx. 150 L	Approx. 150 L Approx. 600 L		
Water Quality	μS/cm	Approx. 150 L			
Working Water Pressure	MPa	0.05 – 0.2 *5			
Working Water Temperature	°C	5 – 40			
Dimensions		Φ74.5, H : 248 mm (ion exchange resin)	Ф185, Н : 449 mm	Ф185, H : 592 mm	
Mass	g	Approx. 670 (ion exchange resin)	Approx. 5700	Approx. 8600	
Type of Installation		On the side of the unit	On a	vall *4	
Inlet / Outlet Piping Fixture			Rc1/2		
Included Parts		Spare deionizer *3 ball valve, mounting hardware hose nipple, hose band tee coupling, nipple, hose	Mounting bracket, resin nipple, socket, bushing (preassembled on the filter) filter removal wrench		

- \*1. Processing capacity figure based on water source standard purity level of 150 µS /cm. Capacity may vary according to water quality.
- \*2. Processing capacity is not based on circulating water flow system. Ion exchange resin lifespan and water quality may fluctuate depending on the properties of the wetted parts and surfaces, as well as the particular working environment.
- \*3. It is recommended that the initially supplied water be either water that has been purified by having passed through an ion exchange resin, or be commercially purchased deionized water. If tap water (or a similar grade of water) is used, the effective life of the ion exchange resin will be greatly reduced. In this case, please replace the ion exchange resin with the apare soon. (Ion exchange resin assemblies A, B, C, and F only.)
- \*4. Ion exchange resin assemblies D and E are wall mounted. Please confirm that there is a suitable installation place before installing the filter. An optional Stand Mount is available. (The mounting hole positions of Ion Exchange Resin D and E assemblies are the same as the mounting hole positions on Water Filter A and B assemblies respectively. Please refer to the Water Filter Equipment page for details regarding dimensions.)
- \*5. On Ion Exchange Resin D and E assemblies, if there is a chance that the water pressure within the purification vessel will exceed 0.2 MPa, a pressure reducing valve should be installed. Note: Avoid installing the ion exchange resin where it will be in direct sunlight or in places where there is a risk of it being damaged.

### For Water Supply and Purification (Keeps sudden rises in electrical conductivity down during water tank supply and replenishment.)

Model		Model Deionizer Assembly for Water Supply
Part Number		04100522010
Applicable Purifier		AP-10
Processing Capacity *1,2	L	Approx. 2200
Water Quality	μS/cm	1 or less
Working Water Pressure	MPa	0.34 or less *3
Working Water Pressure	°C	5 to 40
Dimensions		Ф165, H : 851 mm
Unit Mass	kg	approx. 15
Inlet Connection		Universal faucet adaptor
Outlet Connection		Braided hose (Φ12 × Φ18)
Ion Exchange Resin Part Number		0A001213000
Comments		Electrical conductivity gauge (0 – 3 µS/cm) included Flow regulating valve (2.2 L/min) included 3 anchor bolt holes (Ф10 mm × 3)

<sup>\*1</sup> For water tank supply and replenishment.

Note: Avoid installation of the deionizer where it will be in direct sunlight or in places where there is a risk of it being damaged.



<sup>\*2</sup> Processing capacity figure based on water source standard purity level of 200 µS/cm. Actual processing capacity may change depending on water quality, temperature, etc.

<sup>\*3</sup> If there is a chance that the water pressure within the vessel will exceed 0.34 MPa, a pressure reducing valve should be

WARNING = Failure to follow instructions contained in a WARNING may result in death or serious injury

**CAUTION** = Failure to follow instructions contained in a CAUTION may result in injury to the operator or damage to property.

### Pre-Unloading and Unloading Procedures

After unpacking, check the nameplate of the unit to ensure it is the correct model ordered. Also, check that the below mentioned included parts are present.


Machine Part Name	Specifications	Qty Per Unit
	40 mesh equiv. Pipe connection: 1B Model: RKE3750 – 7500B-V/B-VW	
Y-Strainer	40 mesh equiv. Pipe connection: 1.1/4B Model: RKE11000B-V/B-VW, RKE15000B-V/B-VW	1 pc
	40 mesh equiv. Pipe connection: 2B Model: RKE22000B-V, RKE30000B-V	
	1B × 100 L (to attach the Y-strainer) Model : RKE3750 – 7500B-V/B-VW	
Barrel Nipple	1.1/4B × 100 L (to attach the Y-strainer) Model: RKE11000B-V/B-VW, RKE15000B-V/B-VW	1 pc
	2B (to attach the Y-strainer) Model: RKE22000B-V, RKE30000B-V	

It is possible that the unit could be damaged during shipping, transport, or other handling. When receiving the unit, check to make sure that there are no scratches or other abnormalities. If any damage or abnormality is detected, please contact the dealer where the unit was purchased.



### WARNING


When making use of the evebolts, suspend the unit from all 4 eyebolts and make sure there is at least a 60° angle between the top face of the unit and each of the suspension cables. Improper suspension may lead to the unit tipping over or falling, which could result in injury.



### Unloading Procedure

The unit is heavy; please be careful when transporting it. The unit has rectangular slots at its base in order to accept forklift tines. When lifting the unit by forklift, make sure the forklift tines go through the forklift slots all the way and protrude from the other side of the unit.

Model	Mass (when water tank is empty)	
RKE3750B-VW-G1 : No casters	200 kg	
RKE3750B-VW-G2 : Casters included	205 kg	
RKE5500B-V/VW	280 kg	
RKE7500B-V/VW	290 kg	
RKE11000B1-V	415 kg	
RKE11000B1-VW	405 kg	
RKE15000B-V	460 kg	
RKE15000B-VW	405 kg	
RKE22000B-V	1050kg	
RKE30000B-V	1065kg	



### WARNING

Installation of this equipment should be performed by your dealer or other qualified personnel. Improper installation by the end user may lead to water leakage, electric shock, and fire.

### **Unit Placement**

### Choice of Installation Location

Choose an installation location that is free from combustible materials, areas that could lead to electric shock, or environments that could lead to unit breakdown.



### CAUTION

Install on a level surface that can adequately support the weight of the unit and fix the unit down with anchor bolts to prevent it from moving around. Not properly installing the equipment as indicated can result in water leaks or injury etc., from the unit tipping over or falling.

- 1. Ensure there is adequate space for heat ventilation as well as sufficient space for maintenance and inspection of the unit. Also note that if the unit is enclosed as in the illustration below, exhaust heat from the unit will be forced back into the unit, causing the refrigerant pressure to rise, and eventually causing the unit to stop.
- 2. If the unit will be installed where a wind of 8 m/s or higher will be blown on it, measures to block the wind from hitting the unit such as installation of a wind-break panel or wall is required.
- 3. Install out of direct sunlight and do not install where the unit would be affected by heat. Contact with direct sunlight or heat can cause the unit



- and sides of the unit, then the space from the top of the unit to the obstacle above can be as low as 100
- For RKE22000B-V and 30000B-V models, ensure there is at least 300 cm clearance above the product and there are no obstacles within 100 cm of the front, back and sides. Model in the illustration: RKE3750B-V.



to perform below specified performance equal to the amount of that exposure. It can also lead to the activation of built-in safety devices which will prevent unit operation.

Air cooled: Operate the unit in the ambient temperature of -20 to 45 °C. Operating outside this temperature range can lead to breakdown of the compressor. And operating in temperatures over 45 °C will result in a drop in the effectiveness of thermal radiation of the condenser. Built-in safety devices may activate causing the unit to shut down. If the ambient temperature will be above 45 °C, install ducting, following the section on page 28, "Ducting Design Points".

Water cooled: Operate the unit in the ambient temperature of 2 to 45 °C. Operating outside this temperature range can lead to breakdown of the

When performing ductwork, install such that the piping is not constricted along the way. Failure to follow this rule can also lead to activation of built-in safety devices which will stop unit operation.

- 5. Install in a place that is generally free of dust and dirt. Installation in places with heavy dust and dirt can result in reduction of unit performance.
- 6. Note that operating air-cooled models solely in the Snow-Protection Mode in areas that heavy snowfall will result in reduced performance. It is therefore recommended that the unit be installed away from falling snow. (Air cooled only)
- 7. Operate the product at a cooling water temperature within the range of 5 to 45 °C. If operated outside the specified range, the safety device will be activated to shoutdown the product. It can also cause the compressor to malfunction. (Water cooled only)











RKE37	750B-V	RKE3750B-V	RKE5500B-V	RKE7500B-V	RKE11000B1-V	RKE15000B-V	RKE22000B-V	RKE30000B-V
	Top View			300				
Maintenance and	Front View			10	00			
Inspection	Left/Right Views			80			10	00
Space (cm)	Rear View	0					10	00
(6)	Top View			200			30	00

### **Water Supply and Drainage Construction**

- Reliably install water supply and drainage piping. Improper water supply and drainage construction could result in water spraying out, causing water damage to the surrounding area.
- Keep water supply pressure at or below 0.50 MPa. Too high pressure can lead to equipment damage, which may lead to water leaks, flooding of the surrounding area, and electric shock.
- Keep the cooling water pressure below 0.69 MPa. Higher pressure may damage the components to cause water leakage and may result in electric shock.
- . When performing water piping, be careful to avoid the following

### points. Failure to do so can result in water leakage.

- 1. Overtightening the piping connected to the water supply port.
- 2. Having external forces on the water supply port.
- 3. Piping installation that does not absorb vibrations of water hammer, etc.
- When connecting piping to the water supply port, always use two tools, using one to support the ball tap valve, as shown in the illustration to the right.



### Chilled Water / Cooling Water Piping

### Piping Sizes

Piping diameters for each model are listed below.

	Piping Size					
Piping Item	RKE3750B-V/VW	RKE5500B-V/VW RKE7500B-V/VW	RKE11000B1-V/VW RKE15000B-V/VW			
Chilled Water Inlet	R	Rc1				
Chilled Water Outlet	Rc1		Rc1.1/4			
Water Tank Drain	Rc1/2	Rc1/2				
Overflow Port		Rp1				
Drain Pan Drain Port		Rc1/2				
Water Supply Port		PJ1/2				
Cooling Water Inlet	Rc1 (Water	cooled only)	Rc1.1/4 (Water cooled only)			
Cooling Water Outlet	Rc1 (Water	cooled only)	Rc1.1/4 (Water cooled only)			

Piping Item	Piping Size					
Fibility item	RKE22000B-V, RKE30000B-V					
Chilled Water Inlet	Rc2					
Chilled Water Outlet	Rc2					
Water Tank Drain	Rc1					
Overflow Port	Rp1					
Drain Pan Supply Port	R1/2					
Water Supply Port	PJ1/2					
Pressure Equalization Port *	R4					

### • Pipe Connection Procedure (Water cooled)

- Confirm the positions of the Cooling Water inlet and outlet. The Cooling Water inlet and outlet are specified with stickers. ("Cooling Water inlet", "Cooling Water Outlet")
- 2. Follow the instructions below for piping work.
  - (1) Mount the Cooling Water inlet valve <1> and the Cooling Water outlet valve <2>.
  - (2) Be sure to mount the safety relief valve <3>. The regulating valve that is installed in the cooling water circuit performs the opening and closing of the valve automatically by detecting the refrigerant pressure. Thus, there is a possibility that the regulating valve becomes full-closed during operation. Be sure to install the safety relief valve for the water leakage prevention in the cooling water circuit, and set the cooling water inlet pressure 0.69 MPa or lower.
  - (3) Install the purge/drain valve <4>
  - (4) Be sure to install the union coupling <5>. Make sure that the product and the cooling water piping can be easily disassembled when carrying out the cleaning of water-cooled condenser inside the product.

\* Only used for linked units.

### Piping Methods

Piping installation should follow the guidelines below.

- 1. Check the cooling water inlet and outlet side ports.
- Make pipe lengths as short as possible, and also avoid vertical and curved piping as much as possible.
- When tightening piping connections, use 2 pipe wrenches or adjustable wrenches in order to grasp both sides of the joint.
- Always install valves (customer supplied) at the chilled water inlet and outlet ports.
- 5. Install the included Y-strainer on the chilled water intake side port.
- 6. Make sure that there is no excessive weight or vibration directed on the unit from the connected piping. long horizontal piping should be supported with additional support hardware to ensure unreasonable forces are not applied directly to the unit's connection ports. Failure to properly support piping can lead to equipment damage.
- Piping should be insulated. (Install the pipe insulation such that there is enough gap to allow the removal of the cabinet water supply port.)
- 8. If an automatic water supply system is to be installed, be sure to install a valve on the supply port.


  Also, keep water supply pressure at or below 0.50


  MPa

  Chilled

  T

  Chilled
- Always support water supply piping with support fittings, and make sure that piping is horizontal.






### Electrical Wiring

### • Correct Wiring Installation

When performing electrical wiring, be sure to carefully follow the guidelines listed below.



- 1. Chose a power cable based on the breaker capacity shown in the table to the right. Hook up the ground wire to the earth (ground) terminal located in the distribution box. Also, regarding the power and signal terminal block, refer to the chart on the right for the screw size and terminal block width.
- There is a combined use overload protection and earth leakage breaker installed inside the distribution box and the specifications are in the table to the right.
- 3. Route the power cord through the power cord access hole, located on the lower-right part of the unit, to the inside of the terminal box. (Use 1 of the 2 available power cord access holes. The other can be used for remote control panel connections, etc.) Connect the power cord to the L1, L2, and L3 terminals on the terminal block. Fix the power cord in place with a cable tie.
- 4. Always properly ground this unit. Connect the ground wire to a proper earth/ground point that has been installed by a qualified electrician. Furthermore, the diameter of the grounding wire must be at least 2 mm².
  \* Prepare the ground wire terminal of a size according to the screw size listed in the table to the right.
- Ensure the source voltage is within ±10% of the specified voltage. Also make sure the source voltage phase unbalance is within ±3%.

			RKE3750B-V/	VW	RKE5500, RKE	7500B-V/VW	RKE11000B1,	15000B-V/VW
	ver Source cooled			Three-phase 200 to 220 ±10% (50/60)				
(\	/•Hz)	Water cooled	Three-	Three-phase 200 ±10% (50), 200 to 220 ±10% (60)				% (60)
	Screw	Power		M5 M6				6
Ş≡	Size	Signal				M3		
Terminal Block	Terminal Block Width	Power	12		13	3	17	7
	(mm)	Signal		5.9				
			RKE3750B-V/VW	RKE	5500, 7500B-V/VW	RKE11000B1-V/V	V RKE15000B-V	RKE15000B-VW
Brooker Consoity (A)			20		EO	75	100	75

	TUREDIOOD VIVII	Tuteou	00, 10000 17111	THILL THOUGHT WITH	THILL TOUGOD V	THE TOOLOG THE	
Breaker Capacity (A)	30		50	75	100	75	
Current Sensitivity (mA)	30				100		
	DKE3750	5500	7500R \//\/	W DKE1100	10D1 1500	10B \/\/\/\	

	RKE3750, 5500, 7500B-V/VW	RKE11000B1, 15000B-V/VW
Ground Terminal	M5	M6

			RKE22000B-V	RKE30000B-V		
Powe	wer Source (V•Hz)		Three-phase 200 to 220 ±10% (50/60)			
_	Screw	Power	M	8		
S a	Size	Signal	M	3		
eminal Block	Terminal	Power	23			
-	Block Width (mm)	Signal	5.	9		
Brea	Breaker Capacity (A	y (A)	125	175		
Curre	nt Sensitivity	/ (mA)	10	00		
Gro	Ground Terminal		M	8		

\* Phase unbalance (%) = ( Maximum voltage [V] - Minimum voltage [V] )  $\div$  Average voltage of 3 phases (V) × 67. (Based on IEC61800-3.)

### <IMPORTANT>

- Make sure the power cord does not come into contact with the refrigerant piping or any motor within the unit. Contact with hot surfaces could cause the cord to melt, resulting in an electrical short. (Secure the power cable with the cable tie inside the distribution box.)
- Never operate the unit when the water circuit is empty. Always fill the water tank and confirm the water level before operating.
- Do not attempt to perform withstand voltage tests or insulation resistance tests.
   Doing so can damage the semiconductors used in the chiller control board or inverter. If the tests are deemed necessary, please consult with your dealer.

### **If Employing Remote Control Operation**

- Information Regarding Remote Operation and Communications Functions
  Perform the wiring after confirming the required specifications.
- \* Please prepare terminals that fit M3 size screws.
- 1. Please confirm the unit specifications which are as follows.

Remote Operation Input Specifications	No-voltage contacts input (altern Maximum cable length: Input resistance: Open circuit voltage (Voc): Short circuit current (Isc):	ate switch) 20 m 1200 Ω 12 V DC 10 mA DC		
Signal Output Specifications	No-voltage relay contact output (c contact)     250 Vac / 30 Vdc, 5 A (resistance load) (normally opei     250 Vac / 30 Vdc, 3 A (resistance load) (normally clos     Minimum operating current (for reference only) 5 Vdc, 10			

2. Remote operation and signal output terminals are as follows:

Remote	Remote Operation	20 0
Terminals Remote Discharge Pump Operation		23
		When power source is cut off: 24 – 26 closed, 25 – 26 open
	Operating Signal	Unit operation is stopped and the unit is operating in pump-only mode: 24 – 26 closed, 25 – 26 open
		26 Equipment operating: 24 – 26 open, 25 – 26 closed
Signal	Alarm Signal	When power source is cut off: 27 – 29 closed, 28 – 29 open
Output Terminals		28 No alarm : 27 – 29 closed, 28 – 29 open (initial setting)
Terriniais		29 During alarm: 27 – 29 open, 28 – 29 closed (initial setting)
		30 When power source is cut off: 30 – 32 closed, 31 – 32 open
	Warning	31 No temperature warning: 30 – 32 closed, 31 – 32 open (initial setting)
	Signal	32 During temperature warning: 30 – 32 open, 31 – 32 closed (initial setting)

### When Using Communications Functions


	USB	Connector: USB type B connector     Data cable max. length: 3 m.     May differ depending on specific operating conditions.
RS-422A • Data cable wire size (RS-485) • Data cable max. le		Attach the stripped wires and use as is.     Data cable wire size: AWG16 – 26     Data cable max. length: 100 m. (from host to terminal end)     May differ depending on specific operating conditions.

### • Communications Cables and Connectors

### 1. USB

- <1> Compatible connector: Type B (male) connector
- <2> Maximum cable length: 3 m. However, it may be shorter depending on actual operating conditions.
- 2. RS-422A (RS-485)
  - (1) Connector: Terminal block
  - (2) Cable Gauge: AWG16 26 (Use AWG18 24 if 2 wires are to be inserted into a single terminal connection.)
  - (3) Length of Insulation to Remove From Cable: 10 mm
  - (4) Attaching the Cables: Use either of the following methods: Attach the stripped wires as is. When performing hookups, be careful not to allow frayed wires to come into contact with or short out nearby wiring.
  - (5) Maximum Cable Length: 100 m or less -- May differ depending on operating conditions.
  - (6) Connection Example
- \* If connecting via RS-422A/485, make the connection by purchasing and using an RS-232C/422A converter.

Example of Commercially Available Connector : Network Supply Inc. GPNET232-485CT (Main Unit) GP-259RS (DOS/V PC 9-Pin Connector), SFN-830 (AC Adapter)



### **Ducting Design Points (Air cooled only)**

### • Ducting Design Points (For User Installed Ducting)

If the area where the unit is to be installed is narrow or has a low ceiling, the ambient temperature could raise to above 45 °C from the heat coming from the ventilation outlet. In such cases, ducting should be used to move the heat outside of the room or at least away from the unit so that the effects of it do not cause the temperature around the unit to rise. Take the following into consideration when planning duct work.

### 1. Duct cross sectional area

### (1) For duct that rises up:


	RKE3750B-V	RKE5500, 7500B-V	RKE11000B1, 15000B-V
Minimum Cross Sectional Area (m²) [B×W]	0.429	0.611	0.8
Maximum Length (m)	20	20	20

	RKE22000B-V, RKE30000B-V Right Unit	RKE22000B-V, RKE30000B-V Left Unit
Minimum Cross Sectional Area (m²) [B×W]	0.64	0.64
Maximum Length (m)	20	20


### (2) Rectangular ducting with bends:

- The cross sectional area should be greater than above, and Lx and Ly should be less than 2 m. (See Fig. 1.)
- If the length of Lx and Ly go over 2 m, then there should be a 20 cm gap between the hot exhaust air outlet from the unit and a fan should be installed on the duct outlet. Do not allow Lx and Ly to be longer than 5 m. (See Fig. 2.)

### Fig. 1 Examples of Bent Rectangular Ducting



\* The duct in the figure is one example. The particular direction the duct exhaust port goes from the unit does not matter, however the following important points must be enforced.



Model		RKE3750B-V	RKE5500, 7500B-V	RKE11000B1, 15000B-V
Recommended 50 Hz		EWF-50FTA	EJ-80FTC3	EWF-50FTA
		(Mitsubishi Electric Corporation)	(Mitsubishi Electric Corporation)	(Mitsubishi Electric Corporation) × 2
Fan	60 Hz	EWG-50ETA	EWG-60FTA	EWG-50ETA
	power	(Mitsubishi Electric Corporation)	(Mitsubishi Electric Corporation)	(Mitsubishi Electric Corporation) × 2
Minimum Required Airflow (m³/min)		119	186	119 × 2

Model	RKE22000B-V, RKE30000B-V
Recommended Fan	ZN080-ZIH, DG, V5P4 (ZIEL-ABEGG) × 2
Minimum Required	233 × 2

### <IMPORTANT>

Do not have anything such as walls or other obstacles that could obstruct exhaust output within 2 m of the unit in the direction of the duct exhaust output. Failure to follow this rule will result in decreased air flow, the main unit heat ventilation will be insufficient, and built-in safety devices may activate, which would cause unit operation to stop.

### • Installing Ducting on the Unit


If ducting is to be affixed to the unit, first remove the suspension eyebolts from the top and replace them with M size bolts of the appropriate size. In this case, install ducting such that at least 50 cm of ducting above the product can be removed when needed in order to allow for easy fan maintenance and inspection.


Model	Α	В	С	D	Е	M Screw
RKE3750B-V	720	725	655	654.6	35.3	M10
RKE5500, 7500B-V	869.5	825.2	804.5	758.6	31.5	M16
RKE11000B1-V	1379	827	1314.2	758.6	33.7	M16
RKE15000B-V	1609	827	1544.2	758.6	33.7	M16


### <IMPORTANT>

Unit: mm

• If ducting is to be affixed directly on the unit, be sure to install support hardware along the ducting in order to prevent the unit from tipping over.







### Points to Follow to Achieve Performance Specifications

### • Important Points to Ensure Optimum Product Performance

 Note the operating ranges and always operate the unit within these ranges. Operating outside the designated ranges can lead to unit breakdown.

Clause	RKE3750, 5500, 7500B-V/VW	RKE11000B1, 15000B-V/VW			
Ambient Temp Range (°C)	-20 to 45 (Air cooled) / 2 to 45 (Water cooled)				
Liquid Temp Range (°C)	3 to 35				
Power (V•Hz)	200 to 220 ±10% (50/60 : Air cooled) 200 ±10% (50 : Water cooled), 200 to 220 ±10% (60 : Water cooled)				
Discharge Pump Operating Pressure (Mpa)	0.08 to 0.50	0.08 to 0.80			

- 2. Do not use aluminum parts for parts that will be wetted with the chilled water. The unit's water circuits operate with parts made of copper or copper alloys, so if user-installed wetted parts containing aluminum are present, the resulting copper ions will lead to electrolytic corrosion and copper deposits, which can cause water leakage around mechanical seals and clogging in the heat exchanger.
- Please consult your dealer before using any corrosion inhibiting water additives. Troubles such as the water becoming dirty, or damage to the refrigeration unit from clogging etc. can result depending on the type of additive used.
- 4. Always apply power to the unit at least 12 hours before performing initial test runs or after the unit has been unpowered for 24 hours or more. Failure to apply power in advance as directed can lead to damage to the refrigeration compressor.
- Operating with antifreeze rust inhibitor additives can reduce the lifespan of the mechanical seals.

### <IMPORTANT>

Do not operated with the discharge pump circuit (cooling water inlet/outlet) blocked. Operating the unit with the circuit blocked can result in freezing or damage of the evaporator, breakdown of the discharge pump, disconnection of hoses, or other trouble.

- If a brine solution is to be used for freeze prevention then in order to maintain cooling capacity, using a 40% or weaker solution of ethylene glycol and water is recommended. However, note that use of a solution of 30% or less can result in decomposition of the liquid. Therefore freeze-prevention by means of automatic pump operation is recommended.
- Frequent starting and stopping can lead to unit breakdown. Allow at least 5 minutes between starting and stopping the unit. If the unit is started less than 5 minutes after stopping, warning "C064" or "C065" will be generated.
- Always fill the water tank and check the water level before operating. If the water level gauge goes below the "E" mark, alarm "E006" will occur and the unit cannot be operated.
- The water pressure at the water supply port should be 0.50 MPa or less. Too high pressure will result in the water supply failing to shut off or leakage.
- Always keep the water clean, inspect the water circuits monthly, and replace the water when necessary.
- Clean the condenser filter every month.
- Water cooled: The cooling water should be checked monthly to ensure that it is clean. The water should be changed if dirty.

### **Chilled Water**

### Chilled Water Standards

The recommended liquid (chilled water) that can be used is either clean water (see chart below for water quality standard) or a 30 to 40% ethylene glycol solution. Alternatively, if deionized water is to be used, it should have

	Item	Standard Levels
ıts	pH (25 °C)	6.8 – 8.0
Jer	Conductivity (µS/cm) (25 °C)	1 – 400
pol	Chloride Ion (mgCl <sup>-</sup> /L)	Max. 50
om	Sulphate (mgSO <sub>4</sub> <sup>2-</sup> /L)	Max. 50
C	Acid Consumption (pH 4.8) (mgCaCO <sub>3</sub> /L)	Max. 50
larc	Total Hardness (mgCaCO <sub>3</sub> /L)	Max. 70
Standard Components	Calcium Hardness (mgCaCO <sub>3</sub> /L)	Max. 50
St	Silica Ion (mgSiO <sub>2</sub> /L)	Max. 30

an electrical conductivity of at least 1  $\mu\text{S}/\text{cm}.$  Cooling non-approved liquid can result in equipment damage, leaking, and possible electric shock or electrical shorts.

		Item	Standard Levels
		Iron (mgFe/L)	Max. 1.0
L	ce	Copper (mgCu/L)	Max. 1.0
	Reference Components	Sulfide Ion (mgS <sup>2-</sup> /L)	Not detected
	np.	Ammonium Ion (mgNH₄⁺/L)	Max. 1.0
_	2 3	Residual Chlorine (mgCl/L)	Max. 0.3
		Free Carbon Dioxide (mgCO <sub>2</sub> /L)	Max. 4.0

<sup>\*</sup> Excerpt from JRA-GL-02-1994 guidelines from The Japan Refrigeration and Air Conditioning Industry Association.

### **Cooling Water**

### Water Selection

Water for the water-cooled condenser may be ground water, municipal water, or cooling-tower water. Refer to the following water quality standard for guidance in selecting the water type.

### • Water Quality Standard Guidelines

Primary cooling water (refrigeration unit condenser cooling water, constant temperature water for the water temperature controller, and humidification water) should meet the water quality standard as described in the chart on the right

- Standard Concentration Levels for Primary Cooling Water
  - (1) If tap water is used as the primary cooling water for water cooled equipment, then the water should meet the following water quality standard.
  - (2) "o" marks in a tendency column show the factor related to either corrosion or scale generation tendency.
  - (3)The 15 items listed to the right are the primary components that can lead to corrosion or scaling.

		Cooling	Water	Tendencies	
Clause		Circulation Water	Supplied Water	Corrosion	Scaling
	pH (25 °C)	6.5 to 8.2	6.0 to 8.0	0	0
S	Electric Conductivity (μS/cm) (25 °C)	800 or below	300 or below	0	0
em	Chloride Ion (mgCl <sup>-</sup> /L)	200 or below	50 or below	0	
Standard Items	Sulfate Ion (mgSO <sub>4</sub> <sup>2-</sup> /L)	200 or below	50 or below	0	
dar	Acid Consumption (pH4.8) (mgCaC <sub>3</sub> /L)	100 or below	50 or below		0
ţa	Total Hardness (mgCaCO <sub>3</sub> /L)	200 or below	70 or below		0
ဟ	Calcium Hardness (mgCaCO <sub>3</sub> /L)	150 or below	50 or below		0
	Ionic Silica (mgSiO <sub>2</sub> /L)	50 or below	30 or below		0
	Iron (mgFe/L)	1.0 or below	0.3 or below	0	0
Items	Cu (mgCu/L)	0.3 or below	0.1 or below	0	
	Sulfide Ion (mgS <sup>2-</sup> /L)	None detected	None detected	0	
nce	Ammonium Ion (mgNH <sub>4</sub> <sup>+</sup> /L)	1.0 or below	0.1 or below	0	
Reference	Residual Chlorine (mgCl/L)	0.3 or below	0.3 or below	0	
Ref	Free Carbon Dioxide (mgCO <sub>2</sub> /L)	4.0 or below	4.0 or below	0	
	Stability Index	6.0 to 7.0	_	0	0

<sup>\*</sup> Excerpt from JRA-GL-02-1994 guidelines from The Japan Refrigeration and Air Conditioning Industry Association.

# **RKE-A/RKED Series**

See page 26 for RKE-B

WARNING = Failure to follow instructions contained in a WARNING may result in death or serious injury



**CAUTION** = Failure to follow instructions contained in a CAUTION may result in injury to the operator or damage to property.

### Pre-Unloading and Unloading Procedures

### Before Unloading


After unpacking, check the nameplate of the unit to ensure it is the correct model ordered. Also, check that the below mentioned included parts are

Part Name	Specifications	Qty Per Unit
	40 mesh equiv., 1B Model : RKED2200A-V/A-VW RKED9000A-V	1 pc.
Y-Strainer	40 mesh equiv., 1.1/4B Model : RKE18000A-V/A-VW	1 pc.
	40 mesh equiv., 2B Model : RKE22000A-VW RKE30000A-VW	1 pc.
	1B (To attach the Y-strainer) Model : RKED2200A-V/A-VW RKED9000A-V	1 pc.
Nipple	1.1/4B (To attach the Y-strainer) Model : RKE18000A-V/A-VW	1 pc.
	2B (To attach the Y-strainer) Model : RKE22000A-VW RKE30000A-VW	1 pc.

It is possible that the unit could be damaged during shipping, transport, or other handling. When receiving the unit, check to make sure that there are no scratches or other abnormalities. If any damage or abnormality is detected, please contact the dealer where the unit was purchased.

### WARNING


When making use of the eyebolts, suspend the unit from all 4 eyebolts and make sure there is at least a 60° angle between the top face of the unit and each of the suspension cables. Improper suspension may lead to the unit tipping over or falling, which could result in injury.



### Unloading Procedure

The unit is heavy; please be careful when transporting it. The unit has rectangular slots at its base in order to accept forklift tines. When lifting the unit by forklift, make sure the forklift tines go through the forklift slots all the way and protrude from the other side of the unit.

Model	Mass (Dry weight)
RKED2200A-V	240 kg
RKED2200A-VW	230 kg
RKED9000A-V	435 kg
RKE18000A-V	approx. 660 kg
RKE18000A-VW	610 kg
RKE22000A-VW	approx. 1100 kg
RKE30000A-VW	approx. 1420 kg





### WARNING

Installation of this equipment should be performed by your dealer or other qualified personnel. Improper installation by the end user may lead to water leakage, electric shock, and fire.

### **Unit Placement**


### Choice of Installation Location

Choose an installation location that is free from combustible materials, areas that could lead to electric shock, or environments that could lead to unit breakdown

## CAUTION

Install on a level surface that can adequately support the weight of the unit and fix the unit down with anchor bolts to prevent it from moving around. Not properly installing the equipment as indicated can result in water leaks or injury etc., from the unit tipping over or falling

1. Ensure there is adequate space for heat ventilation as well as sufficient space for maintenance and inspection of the unit. Also note that if the unit is enclosed as in the illustration below, exhaust heat from the unit will be forced back into the unit, causing



If there are no obstacles within 150 cm of the front and sides of the unit, then the space from the top of the unit to the obstacle above can be as low as 100 cm or higher.



the refrigerant pressure to rise, and eventually causing the unit to stop.

If the unit will be installed where a wind of 8 m/s or higher will be blown on it, measures to block the wind from hitting the unit such as installation of a wind-break panel or wall is required.

- 3. Install out of direct sunlight and do not install where the unit would be affected by heat. Contact with direct sunlight or heat can cause the unit to perform below specified performance equal to the amount of that exposure. It can also lead to the activation of built-in safety devices which will prevent unit operation.
- 4. Air cooled: Operate the unit in the ambient temperature of -5 °C 43 °C. Operating outside this temperature range can lead to breakdown of the compressor. And operating in temperatures over 43 °C will result in a drop in the effectiveness of thermal radiation of the condenser. Built-in safety devices may activate causing the unit to shut down. If the ambient temperature will be above 43 °C, install ducting, following the section on page 32, "Ducting Design Points"

Water cooled: Operate the unit in the ambient temperature of 2 °C - 43 °C. Operating outside this temperature range can lead to breakdown of the compressor.

When performing ductwork, install such that the piping is not constricted along the way. Failure to follow this rule can also lead to activation of built-in safety devices which will stop unit operation.

- 5. Install in a place that is generally free of dust and dirt. Installation in places with heavy dust and dirt can result in reduction of unit performance.
- 6. Note that operating air-cooled models solely in the Snow-Protection Mode in areas that heavy snowfall will result in reduced performance. It is therefore recommended that the unit be installed away from falling snow. (Air cooled only)
- 7. Operate the product at a cooling water temperature within the range of 5 °C to 34 °C. If operated outside the specified range, the safety device will be activated to shoutdown the product. It can also cause the compressor to malfunction. (Water cooled only)

Item		RKED2200A-V	RKED9000A-V	RKE18000A-V	RKED2200A-VW RKE18000A-VW RKE22000A-VW RKE30000			RKE30000A-VW
	A 200			-				
Maint. & Insp. Space (cm)	ВС	80 – 10 or more			80 100		00	
(6)	Rear			10 or more	-			
Ambient Temp	(°C)	-5 to 43			2 to 43			
Cooling Water Ten	Cooling Water Temp (°C)				5 to 34			

# Important Unloading and Placement Information RKE-A•RKED Series

### **Water Supply and Drainage Construction**

- Reliably install water supply and drainage piping. Improper water supply and drainage construction could result in water spraying out, causing water damage to the surrounding area.
- Keep water supply pressure at or below 0.50 MPa. Too high pressure can lead to equipment damage, which may lead to water leaks, flooding of the surrounding area, and electric shock.
- Keep the cooling water pressure below 0.69 MPa. Higher pressure may damage the components to cause water leakage and may result in electric shock.
- When performing water piping, be careful to avoid the following points. Failure to do so can result in water leakage.
- Overtightening the piping connected to the water supply port.
- 2. Having external forces on the water supply port.
- 3. Piping installation that does not absorb vibrations of water hammer, etc.
- When connecting piping to the water supply port, always use two tools, using one to support the ball tap valve, as shown in the illustration to the right.

### **Chilled Water / Cooling Water Piping**

### Piping Sizes


Piping diameters for each model are listed below.

Dining Itom	Piping Size							
Piping Item	RKED2200A-V	RKED2200A-VW	RKED9000A-V	RKE18000A-V	RKE18000A-VW	RKE22000A-VW	RKE30000A-VW	
Chilled Water Inlet		Rc1		Rc1	.1/4	R	c2	
Chilled Water Outlet	Rc1			Rc1	.1/4	R	c2	
Water Tank Drain	Rc1/2 Rc3/4					Rc1		
Overflow				Rp1				
Drain Pan Drain Port			Rc1/2			Rc1/2, 3	locations	
Water Supply Port	Rp1/2							
Cooling Water Piping Inlet	- Rc1 -			-	Rc1.1/2	Rc2	Rc2	
Cooling Water Piping Outlet	-	Rc1	-	-	Rc1.1/2	Rc2	Rc2	

### Piping Methods


Piping installation should follow the guidelines below.

- 1. Check the cooling water inlet and outlet side ports.
- Make pipe lengths as short as possible, and also avoid vertical and curved piping as much as possible.
- 3. When tightening piping connections, use 2 pipe wrenches or adjustable wrenches in order to grasp both sides of the joint.
- Always install valves (customer supplied) at the chilled water inlet and outlet ports.
- 5. Install the included Y-strainer on the chilled water intake side port.
- 6. Make sure that there is no excessive weight or vibration directed on the unit from the connected piping, long horizontal piping should be supported with additional support hardware to ensure unreasonable forces are not applied directly to the unit's connection ports. Failure to properly support piping can lead to equipment damage.
- 7. Piping should be insulated. (Install the pipe insulation such that there is enough gap to allow the removal of the cabinet water supply port.)
- 8. If an automatic water supply system is to be installed, be sure to install a valve on the supply port. Also, keep water supply pressure at or below 0.50 MPa.
- Always support water supply piping with support fittings, and make sure that piping is horizontal.



### • Pipe Connection Procedure (Water cooled)

- Confirm the positions of the Cooling Water inlet and outlet. The Cooling Water inlet and outlet are specified with stickers. ("Cooling Water inlet", "Cooling Water Outlet")
- 2. Follow the instructions below for piping work.
  - (1) Mount the Cooling Water inlet valve <1> and the Cooling Water outlet valve <2>.
  - (2) Be sure to mount the safety relief valve <3>. The regulating valve that is installed in the cooling water circuit performs the opening and closing of the valve automatically by detecting the refrigerant pressure. Thus, there is a possibility that the regulating valve becomes full-closed during operation. Be sure to install the safety relief valve for the water leakage prevention in the cooling water circuit, and set the cooling water inlet pressure 0.69 MPa or lower.
  - (3) Install the purge/drain valve <4>.
  - (4) Be sure to install the union coupling <5>. Make sure that the product and the cooling water piping can be easily disassembled when carrying out the cleaning of water-cooled condenser inside the product.




### Electrical Wiring

### • Correct Wiring Installation

When performing electrical wiring, be sure to carefully follow the guidelines listed below.

\* Photo below shows the piping arrangement of model RKED2200A-V.



Communications Connector (Not on RKE30000A-VW

Power Connection Terminals (RKE-A Breaker Terminals)

Remote and Signal Output

Ground Terminal

Cable Tie (Not on RKE-A models.)

- 1. Chose a power cable based on the breaker capacity shown in the table to the right. Hook up the ground wire to the earth (ground) terminal located in the distribution box. Also, regarding the power and signal terminal block, refer to the chart on the right for the screw size and terminal block width.
- 2. Route the power cord through the power cord access hole, located on the lower-right part of the unit, to the inside of the terminal box. (Use 1 of the 2 available power cord access holes. The other can be used for remote control panel connections, etc.) Connect the power cord to the L1, L2,

- and L3 terminals on the terminal block. Fix the power cord in place with a cable tie.
- 3. Always properly ground this unit. Connect the ground wire to a proper earth/ground point that has been installed by a qualified electrician. Furthermore, the diameter of the grounding wire must be at least 2 mm<sup>2</sup>. Prepare the ground wire terminal of a size according to the screw size listed in the chart to the right.
- 4. Ensure the source voltage is within ±10% of the specified voltage. Also make sure the source voltage phase unbalance is within ±3%
- \* Phase unbalance (%) = ( Maximum voltage [V] Minimum voltage [V] ) ÷ Average voltage of 3 phases (V) × 67. (Based on IEC61800-3.)

- Make sure the power cord does not come into contact with the refrigerant piping or any motor within the unit. Contact with hot surfaces could cause the cord to melt, resulting in an electrical short. (Secure the power cable with the cable tie inside the distribution box.)
- Never operate the unit when the water circuit is empty. Always fill the water tank and confirm the water level before operating.
- Do not attempt to perform withstand voltage tests or insulation resistance tests. Doing so can damage the semiconductors used in the chiller control board or inverter. If the tests are deemed necessary, please consult with

Item		RKED2200A-V	RKED2200A-VW	RKED9000A-V	RKE18000A-V	RKE18000A-VW	RKE22000A-VW	RKE30000A-VW	
F	Power Source (V•Hz)			Three-phase 200 V, 50/60 Hz; three-phase 220 V, 60 Hz					
=	Screwsize Power Signal Terminal Block Power Width (mm)		M4		M8				
ë ₹				M3.5					
Blo	Terminal Block	Power	1	0	19	23			
	Width (mm)	Signal				7.5			
Breaker Capacity (A)		.)	3	80	75	1:	25	17	75
Current Sensitivity (mA)		30		100					
Ground Terminal		-	M5	M6 M8		18			
Ground Treminal (mm²)					2 or more				

### If Employing Remote Control Operation

### • Information Regarding Remote Operation and Communications Functions

Perform the wiring after confirming the required specifications. \* Please prepare terminals that fit M3 size screws.

1. Please confirm the unit specifications which are as follows.

Remote Operation Input Specifications	No-voltage contacts input (alte     Maximum cable length:     Input resistance:     Open circuit voltage (Voc):     Short circuit current (Isc):	ernate switch) 20 m 1200 Ω 12 Vdc 10 mA DC			
Signal Output Specifications	<ul> <li>250 Vac / 30 Vdc, 3 A (resistar</li> </ul>	No-voltage relay contact output (a contact) 250 Vac / 30 Vdc, 3 A (resistance load) (normally closed) Minimum operating current (for reference only) 5 Vdc, 10 mA			

2. Remote operation and signal output terminals are as follows:

	Remote Operation
Remote Operation Contacts	17 18
Signal Output	Operation Signal (Closed during operation)
Contacts	15 Alarm Signal (Closed during alarm condition)

### • When Using Communications Functions

RS-232C	Connector: D sub 9 pin female connector Comm. cable max. length: 15 m. * May differ depending on specific operating conditions.
---------	---

RS-422A (RS-485)	Terminal Block Comm. Cable Size: AWG 16 to 24  * If inserting 2 wires into one location on the terminal block: AWG 18 to 24  * Length of insulation to remove: 10 mm Max. comm. cable length: 100 m. (From host to the end-unit)  * May differ depending on specific operating conditions.

### Ducting Design Points (Air cooled only)

### • Ducting Design Points (For User Installed Ducting)

If the area where the unit is to be installed is narrow or has a low ceiling, the ambient temperature could raise to above 43 °C from the heat coming from the ventilation outlet. In such cases, ducting should be used to move the heat outside of the room or at least away from the unit so that the effects of it do not cause the temperature around the unit to rise. Take the following into consideration when planning duct work.

### 1. Duct cross sectional area


### (1) For duct that rises up:


Model		RKED2200A-V	RKED9000A-V	RKE18000A-V	
Min. Cross Sectional Area (m²) [B×W]		0.303	0.519		
Max. Length (m)			20		
Recommended	50 Hz Power	EWF-40DTA (Mitsubishi Elec. Co.)	EJ-80FTC3 (Mitsubishi Elec. Co.)	EWF-60FTB (Mitsubishi Elec. Co.) × 2	
Fan	60 Hz Power	EWG-40CTA (Mitsubishi Elec. Co.)	EWG-60FTA (Mitsubishi Elec. Co.)	EVVF-60FTB (IVIIISUDISTII EIEC. Co.) * 2	
Min. Req. Air Flow (m³/min)		63	186	186 × 2	

### (2) Rectangular ducting with bends:

- $\circ$  The cross sectional area should be greater than above, and Lx and Ly should be less than 2 m. (See Fig. 1.)
- If the length of Lx and Ly go over 2 m, then there should be a 20 cm gap between the hot exhaust air outlet from the unit and a fan should be installed on the duct outlet. Do not allow Lx and Ly to be longer than 5 m. (See Fig. 2.)
- \* The duct in the figure is one example. The particular direction the duct exhaust port goes from the unit does not matter, however the following important points must be enforced.

Fig. 1 Examples of bent rectangular ducting.






RKED9000A-V

### • Installing Ducting on the Unit

RKED2200A-V

If ducting is to be installed directly onto the product, then use the duct mounting holes located at the top of the product. In such cases, in order to allow for easy fan maintenance and inspection, provide for at least 50 cm of space above the product to allow for removal of the ducting.


Do not have anything such as walls or other obstacles that could obstruct exhaust output within 2 m of the unit in the direction of the duct exhaust output. Failure to follow this rule will result in decreased air flow, the main unit heat ventilation will be insufficient, and built-in safety devices may activate, which would cause unit operation to stop.





### <IMPORTANT>

<IMPORTANT>

• If ducting is to be affixed directly on the unit, be sure to install support hardware along the ducting in order to prevent the unit from tipping over.







### Points to Follow to Achieve Performance Specifications

### • Important Points to Ensure Optimum Product Performance

1. Note the operating ranges and always operate the unit within these ranges. Operating outside the designated ranges can lead to unit breakdown.

Item	RKED2200A-V	RKED2200A-VW	RKED9000A-V	RKE18000A-V	RKE18000A-VW	RKE22000A-VW	RKE30000A-VW
Operable Ambient Temp Range (°C)	-5 to 43	2 to 43	-5 to 43		2 to 43		
Operable Liquid Temp Range (°C)		5 to 35				15 to	o 30
Power (V•Hz)			Three-phase 200 ±10% (50/60), three-phase 220 ±10% (60)				
Discharge Pump Operating Pressure (MPa)	0.5 or lower						

- 2. Do not use aluminum parts for parts that will be wetted with the chilled water. The unit's water circuits operate with parts made of copper or copper alloys, so if user-installed wetted parts containing aluminum are present, the resulting copper ions will lead to electrolytic corrosion and copper deposits, which can cause water leakage around mechanical seals and clogging in the heat exchanger.
- Please consult your dealer before using any corrosion inhibiting water additives. Troubles such as the water becoming dirty, or damage to the refrigeration unit from clogging etc. can result depending on the type of additive used.
- 4. Always apply power to the unit at least 12 hours before performing initial test runs or after the unit has been unpowered for 24 hours or more. Failure to apply power in advance as directed can lead to damage to the refrigeration compressor.
- Operating with antifreeze rust inhibitor additives can reduce the lifespan of the mechanical seals.

### <IMPORTANT>

Do not operated with the discharge pump circuit (cooling water inlet/outlet) blocked. Operating the unit with the circuit blocked can result in freezing or damage of the evaporator, breakdown of the discharge pump, disconnection of hoses, or other trouble.

- If a brine solution is to be used for freeze prevention then in order to maintain cooling capacity, using a 40% or weaker solution of ethylene glycol and water is recommended. However, note that use of a solution of 30% or less can result in decomposition of the liquid. Therefore freeze-prevention by means of automatic pump operation is recommended.
- Frequent starting and stopping can lead to unit breakdown. Allow at least 5 minutes between starting and stopping the unit. If the unit is started less than 5 minutes after stopping, warning "C064" or "C065" will be generated.
- Always fill the water tank and check the water level before operating. If the water level gauge goes below the "E" mark, alarm "E006" will occur and the unit cannot be operated.
- The water pressure at the water supply port should be 0.50 MPa or less. Too high pressure will result in the water supply failing to shut off or leakage.
- Always keep the water clean, inspect the water circuits monthly, and replace the water when necessary.
- Clean the condenser filter every month
- Water cooled: The cooling water should be checked monthly to ensure that it is clean. The water should be changed if dirty.

### **Chilled Water**

### Chilled Water Standards

The recommended liquid (chilled water) that can be used is either cleanwater (see chart below for water quality standard) or a 30 to 40% ethylene glycol solution. Alternatively, if deionized water is to be used, it should have

	Item	Standard Levels
Components	pH (25 °C)	6.8 - 8.0
Jer	Conductivity (µS/cm) (25 °C)	1 – 400
lod	Chloride Ion (mgCl <sup>-</sup> /L)	Max. 50
l mo	Sulphate (mgSO <sub>4</sub> <sup>2-</sup> /L)	Max. 50
Ö	Acid Consumption (pH 4.8) (mgCaCO <sub>3</sub> /L)	Max. 50
darc	Total Hardness (mgCaCO <sub>3</sub> /L)	Max. 70
Standard	Calcium Hardness (mgCaCO <sub>3</sub> /L)	Max. 50
St	Silica Ion (mgSiO <sub>2</sub> /L)	Max. 30

an electrical conductivity of at least 1 µS/cm. Cooling non-approved liquid can result in equipment damage, leaking, and possible electric shock or electrical shorts.

	ltem	Standard Levels		
ce	Iron (mgFe/L)	Max. 1.0		
	Copper (mgCu/L)	Max. 1.0		
e.i.e.	Sulfide Ion (mgS <sup>2-</sup> /L)	Not detected		
Reference Components	Ammonium Ion (mgNH <sub>4</sub> +/L)	Max. 1.0		
	Residual Chlorine (mgCl/L)	Max. 0.3		
	Free Carbon Dioxide (mgCO <sub>2</sub> /L)	Max. 4.0		

<sup>\*</sup> Excerpt from JRA-GL-02-1994 guidelines from The Japan Refrigeration and Air Conditioning Industry Association.

### **Cooling Water**

### Water Selection

Water for the water-cooled condenser may be ground water, municipal water, or cooling-tower water. Refer to the following water quality standard for guidance in selecting the water type.

### Water Quality Standard Guidelines

Primary cooling water (refrigeration unit condenser cooling water, constant temperature water for the water temperature controller, and humidification water) should meet the water quality standard as described in the chart on the right

- 1. Standard Concentration Levels for Primary Cooling Water
  - (1) If tap water is used as the primary cooling water for water cooled equipment, then the water should meet the following water quality standard.
  - (2) "o" marks in a tendency column show the factor related to either corrosion or scale generation tendency.
  - (3) The 15 items listed to the right are the primary components that can lead to corrosion or scaling.


Clause		Cooling	Tendencies		
		Circulation Water	Supplied Water	Corrosion	Scaling
	pH (25 °C)	6.5 to 8.2	6.0 to 8.0	0	0
S	Electric Conductivity (µS/cm) (25 °C)	800 or below	300 or below	0	0
Items	Chloride Ion (mgCl <sup>-</sup> /L)	200 or below	50 or below	0	
d It	Sulfate Ion (mgSO <sub>4</sub> <sup>2-</sup> /L)	200 or below	50 or below	0	
Standard	Acid Consumption (pH4.8) (mgCaC <sub>3</sub> /L)	100 or below	50 or below		0
tan	Total Hardness (mgCaCO₃/L)	200 or below	70 or below		0
S	Calcium Hardness (mgCaCO <sub>3</sub> /L)	150 or below	50 or below		0
	Ionic Silica (mgSiO <sub>2</sub> /L)	50 or below	30 or below		0
	Iron (mgFe/L)	1.0 or below	0.3 or below	0	0
Items	Cu (mgCu/L)	0.3 or below	0.1 or below	0	
	Sulfide Ion (mgS <sup>2-</sup> /L)	None detected	None detected	0	
nce	Ammonium Ion (mgNH <sub>4</sub> +/L)	1.0 or below	0.1 or below	0	
Reference	Residual Chlorine (mgCl/L)	0.3 or below	0.3 or below	0	
Ref	Free Carbon Dioxide (mgCO <sub>2</sub> /L)	4.0 or below	4.0 or below	0	
_	Stability index	6.0 to 7.0	_	0	0

<sup>\*</sup> Excerpt from JRA-GL-02-1994 guidelines from The Japan Refrigeration and Air Conditioning Industry Association.


# **Working Principles and Model Configurations**

### • Working principles -- Diagrams

### ■With Built-In Water Tank (Closed loop)



### Working Principles



The pump built into the unit pumps liquid from the water tank and then through the heat exchanger. There, the liquid is cooled and then returns to the tank. This cycle is repeated and the liquid is continuously cooled until it reaches the desired set temperature, at which time the temperature regulator shuts off the chiller. And if the liquid temperature rises above the set control value, the chiller is automatically started again. In this way, the liquid temperature is maintained and the liquid is pumped out via the discharge pump.

- \* In addition to the discharge pump, some models are equipped with built-in circulation pumps. Please refer to individual model specifications for further details.
- \* The above image is for illustrative purpose only. Please refer to individual model specifications for further details.

### • Making the Right Model Choice

Sample cooler heat calculation and model selection methods are listed below.
 Please make a model choice that best suits your operating conditions and requirements.



Find the cooling capacity required to deal with heat generated by a piece of equipment which is to be cooled by a chilled water flow; the temperature difference between the cooling water going into and out of the equipment is known.

The equipment to be cooled is accepting a cooling water flow of 12 L/min, the water temperature going into the equipment is 17 °C, and the temperature of the water coming out is 20 °C. What is the amount of heat being generated by this equipment?

$$Q = \frac{(t_2 - t_1) \times (X \times 60) \times C}{860} = \frac{(20 - 17) \times (12 \times 60) \times 1}{860} = 2.51 \text{ kW}$$

Note: When making a model selection, also consider heat from external sources that might raise the water temperature. In order to compensate for such external heat sources, it is recommended that an additional 20% in cooling capacity be added to the calculation.

$$Q = 2.51 \times 1.2 = 5.01 \text{ kW}$$



In case a certain temperature drop is required in a fixed amount of time.

For example, if 40 L of 20  $^{\circ}$ C water is in a separate tank, what is the heat dissipation required to lower the temperature of the water to 5  $^{\circ}$ C in one hour?

$$Q = \frac{W \times C \times (t_2 - t_1)}{H \times 860} = \frac{40 \times 1 \times (20 - 5)}{1 \times 860} = 0.7 \text{ kW}$$

- Q: Amount of heat in kW (1 kW = 860 kcal/h)
- W: Weight of cooling liquid (volume x specific gravity)
- C: Relative heat in kcal/kg°C (in case of water: 1)
- t2: Upper temperature (°C)
- t1: Lower temperature (°C)
- H: Required cooling time in hours
- P: Power from an electric heater running 1 hour in kW
- X: Water flow per minute: L/min

\* For coolers that have a built-in water tank, use the capacity of the water tank in place of the volume of water.

Note: When making a model selection, also consider heat from external sources that might raise the temperature of the water in the water tank. In order to compensate for such external heat sources, it is recommended that an additional 20% in cooling capacity be added to the power calculation.

$$Q = 0.7 \times 1.2 = 0.84 \text{ kW}$$



An electric heater with a heat load of 5 kW is to be cooled. The temperature at the cooling water inlet is 17 °C and the temperature at the cooling water outlet is 25 °C. In this case, what is the circulation flow rate required?

$$X = \frac{P \times 860}{(t_2 - t_1) \times 60} = \frac{5 \times 860}{(25 - 17) \times 60} = 9.0 \text{ L/mir}$$



### Orion Products -- Service and Safety

### Safety Notes

- 1. Before using this equipment, read the operating manual thoroughly and operate the equipment correctly as directed
- 2. Consult with a qualified professional or your ORION dealer for product installation and wiring.
- 3. Please select a product that is suitable for the desired application. Do not use for other than intended purposes. Use for other than intended purposes can lead to accidents or unit

### Air-Cooled Spec. Models

If the condenser becomes clogged with dust or dirt, heat exchange will be greatly reduced and electricity consumption will increase. This will lead not only to decreased performance, but can also lead to the activation of built-in safety devices, and eventual damage to the equipment. For these reasons, the condenser should be cleaned on a regular basis.

### Water-Cooled Spec. Models

In general, water used to cool condensers will be well water, tap water, or water from a cooling tower. However water of insufficient quality can lead to scaling in cooling pipes resulting in lower levels of heat exchange, increased electricity consumption and lower performance. Therefore water quality should be confirmed on a regular basis.

### Regarding After Service

- Please contact your dealer for any repairs required after using this unit
- Costs will be incurred by the customer for repairs conducted after the warranty period has expired. In cases where equipment function can be improved by certain service procedures, such procedures will be taken at the specific request of the customer.
- Spare parts are items necessary to maintain the proper function and operating specifications of the equipment. It is the policy of ORION to maintain a stock of replacement parts for 7 years after production of the product ceases.

### Recirculating Chilled Water

The recommended liquid (chilled water) that can be used is either clean water (Note 1) or a 30 to 40% ethylene glycol solution. Alternatively, if deionized water is to be used, it should have an electrical conductivity of at least 1 µS/cm. If the quality of chilled water does not fall within the guidelines, it may result in damage of the mechanical seals, water leaks, electric leak/shock, etc.

### Product Use Limitations

- 1. If the unit is to be used as part of critical installations, safety devices and backup systems which can be switched to should be put into place to insure that serious accidents or losses do not occur in the event that the unit should break down or malfunction.
- 2. This product is designed and produced as a commodity for general manufacturing. Accordingly, the warranty does not apply to nor cover the following applications. However, in cases where the customer/user takes full responsibility and confirms the performance of the equipment in advance, and takes necessary safety precautions, please consult with ORION and we will consider if use of the unit in the desired application is
  - (1) Atomic energy, aviation, aerospace, railway works, shipping, vehicles (cars and trucks), medical applications, transportation applications, and/or any applications where it might have a great effect on human life or property
  - (2) Electricity, gas, or water supply systems, etc. where high levels of reliability and safety are demanded.

### Recommended Maintenance Inspections

• After having used the unit for a long time, actual performance may drop due to the effects of dirt or wear, etc. In order to realize continued best performance of this equipment, in addition to prescribed customer maintenance, it is also recommended that regular inspections be conducted. (Service and inspection fees apply.) For further information please consult with your dealer or contact ORION directly.

ORION is continuing to develop a complete and trustworthy nationwide network of expedient sales and service -- everywhere, anytime



ORION has wide reaching regional service bases in various countries throughout the world.
Please consult your ORION dealer for details.



ISO 9001 ISO 14001 ORION Machinery Co., Itd is an ISO Certified, Quality Management and Environmental Management company.

### What is the ISO certification system?

ISO (International Organization for Standardization) is an established body that stipulates and certifies ISO9001 and ISO14001 directives. ISO9001 stipulates a system of Quality Management that ensures customer satisfaction and trust in a company's products and services it provides. ISO14001 stipulates a system of Environmental Management whereby production and business activities are carried out in an environmentally conscious manner.

For inquiries, please contact the following representative:



### ORION MACHINERY CO.,LTD.

International Group

246, Kotaka, Suzaka-shi, Nagano-ken, 382-8502 Japan TEL +81-(0)26-246-5664 FAX +81-(0)26-246-5022 Email: kokusai@orionkikai.co.jp

Head Office & Factory

246, Kotaka, Suzaka-shi, Nagano-ken, 382-8502 Japan TEL +81-(0)26-245-1230 FAX +81-(0)26-245-5424 URL: https://www.orionkikai.co.jp

### ICHI VIETNAM INDUSTRIAL EQUIPMENT CO., LTD

Address: Lot C15/D21 Cau Giay New Urban Area, Dich Vong Hau,

Cau Giay, Hanoi, Vietnam : +24 3202 3567 Email : sales@ichivina.com.vn Website: www.ichivina.com.vn

This catalog contains product specifications as of Jun. 2020.

- Actual product colors may vary slightly from the pictures.
  Please note that the structure or specifications of products contained in this catalog are subject to change without prior notice.